

JET

ZX Series

METALWORKING LATHE

3219XXT
400/50/3

PARTS LIST
ERSATZTEILLISTE
LISTE DE PIECES

WMH Tool Group AG

Bahnstrasse 24, CH – 8603 Schwerzenbach
www.wmhtoolgroup.ch; info@wmhtoolgroup.ch
Tel +41 (0) 1 806 47 48
Fax +41 (0) 1 806 47 58

P-3219XXT 05/03



Table of Contents

Table of Contents	1
Stand Assembly	2-4
Brake Assembly	5-6
Bed Assembly	7-9
Headstock Assembly I.....	10-12
Headstock Assembly II.....	13-15
Headstock Assembly III.....	16-17
Headstock Assembly IV	18-19
Change Gear Box Assembly I.....	20-21
Change Gear Box Assembly II.....	22-23
Quick Change Gear Box I	24-26
Quick Change Gear Box II	27-28
Quick Change Gear Box III	29-30
Apron Assembly I	31-33
Apron Assembly II	34-36
Apron Assembly III	37-38
Carriage Assembly.....	39-41
Carriage Stop Assembly	42-43
Four Way Tool Post	44-45
Tailstock Assembly I	46-47
Tailstock Assembly II	48-49
Steady Rest Assembly	50-51
Follow Rest Assembly.....	52-53
Coolant And Work Light Assembly	54-55
Micro Carriage Stop Assembly	56
Other Parts	57
Electrical Cabinet	58
Wiring Diagram	59
Protecting guards for three rods	60
Safety guard cover	61


Stand Assembly

Stand Assembly

Index	Part	Description	Size	Qty.
No.	No.			
1	ZX-01101A	Pulley		1
2	ZX-S2	Cylindrical End Set Screw.....	M8x16	1
3	ZX-01734	Cover.....		1
4	ZX-S4	Cross Head Screw	M6x14	4
5	ZX-S2	Cylindrical End Set Screw.....	M8x16	1
6	ZX-01701	Pedal Rod Support.....		1
7	ZX-01715	Lining.....		6
8	TS-1540231	Hex Nut	M24x2	6
9	ZX-01712	Hex Cap Bolt.....		3
9A	ZX-01713	Hex Cap Bolt.....		3
10	ZX-01102A	Bed Stand (for 40" models, serial # 010611ZX349 and lower)		1
	ZX-01102AN	New Bed Stand (for 40" models, serial # 010618ZX350 and higher)		1
	ZX-01102B	Bed Stand (for 60" models, serial # 010611ZX349 and lower)		1
	ZX-01102BN	New Bed Stand (for 60" models, serial # 010618ZX350 and higher)		1
	ZX-01102C	Bed Stand (for 1880ZX, serial # 010611ZX349 and lower)		1
	ZX-01102CN	New Bed Stand (for 1880ZX, serial # 010618ZX350 and higher)		1
11	ZX-01703	Fixed Support.....		2
12	TS-1514021	Socket Head Cap Screw.....	M6x14	4
13	ZX-S13	Taper Pin	5x20	2
14	ZX-01705	Water Leaking Chip Guard		1
15	ZX-S15A	Cross Head Screw	M5x20	4
16	TS-1540121	Hex Nut	M20	9
17	ZX-01702	Bolt		3
18	TS-1550111	Washer.....	A20	6
19	ZX-01122A	Motor Mounting Plate (for 14"models)		1
	ZX-01122B	Motor Mounting Plate (for 16"/18" models)		1
20	ZX-01726	Cover.....		1
21	ZX-S4	Cross Head Screw	M6x14	4
22	ZX-S22	Key	10x8x70	1
23	ZX-S23A	Main Motor (for 14" models).....	7.5HP, 4P, 3Ph	1
	ZX-S23B	Main Motor (for 16"/18" models)	7.5HP, 6P, 3Ph	1
24	ZX-017609A	Wire Conduit (for 1440/1640/1840ZX).....		1
	ZX-017609B	Wire Conduit (for 1460/1660/1860ZX).....		1
	ZX-017609C	Wire Conduit (for 1880ZX)		1
25	ZX-01708	Wire Conduit Support.....		1
26	ZX-01706	Locking Plate.....		1
27	ZX-S27	Cross Head Screw	M5x8	2
28	ZX-S15	Cross Head Screw	M4x6	1
29	ZX-01711	Water Reception Plate		1
30	ZX-S4	Cross Head Screw	M6x14	2
31	ZX-01510	Coolant Tank		1
32	ZX-01714	Cover.....		1
33	ZX-S4	Cross Head Screw	M6x14	6
34	ZX-S34	Nut.....	M3	4
35	ZX-S35	Coolant Indicator.....		1
36	ZX-S36	Cross Head Screw	M3x20	4
37	TS-1540072	Hex Nut	M10	4
38	TS-1550071	Washer.....	M10	4
39	TS-1491041	Hex Cap Bolt.....	M10x30	4
80	ZX-01716A	Stand Front Cover (for 1440/1640/1840ZX)		1
	ZX-01716B	Stand Front Cover (for 1460/1660/1860ZX)		1
	ZX-01716C	Stand Front Cover (for 1880ZX).....		1
81	ZX-01501	Gasket.....		1
82	ZX-S82	Hex Nut	M5	2
83	ZX-01740	Left Tray		1
84	ZX-01741	Right Tray.....		1

Index	Part			
No.	No.	Description	Size	Qty.
85	ZX-01511	Gasket.....		2
86	ZX-S86	Cross Head Screw	M5x16	6
87	ZX-01512	Gasket.....		1
	JX21004	Terminal Board (not shown)		1
	18301	Junction Box (not shown).....		1
	D97-4.....	Plastic Fitting (not shown).....		1
88	ZX-05753	Extending Plate		1


Brake Assembly



Brake Assembly

Index	Part		Description	Size	Qty.
No.	No.				
40	ZX-22101		Fork		1
41	ZX-S41		Spring Pin.....	5x40	1
42	ZX-22703		Butt Nail Support.....		1
43	TS-1524021		Set Screw.....	M8x10	1
44	ZX-S44		Cross Head Screw	M5x20	4
45	ZX-22714		Positioning Plate		1
46	ZX-22704A		Driving Shaft-Longer		1
47	ZX-22705A		Driving Shaft.....		1
48	ZX-S48		Spring Pin.....	5x30	3
49	ZX-22712A		Pedal (for 1440/1640/1840ZX).....		1
	ZX-22712B		Pedal (for 1460/1660/1860ZX).....		1
	ZX-22712C		Pedal (for 1880ZX).....		1
50	ZX-22710A		Draw Bar (for 14" models).....		1
	ZX-22710B		Draw Bar (for 16" models).....		1
	ZX-22710C		Draw Bar (for 18" models).....		1
51	ZX-22706		Connecting Shaft.....		1
52	ZX-S52		Split Pin	2x20	2
53	ZX-S53		Tensile Spring.....	3.5x26x190	1
54	ZX-S54		Eyebolt	M8	1
55	TS-1490091		Hex Cap Bolt.....	M8x50	1
56	TS-1540061		Hex Nut	M8	1
57	ZX-22707A		Butt Rod Support		1
58	TS-1540072		Hex Nut	M10	1
59	ZX-S59		C-Clip	8	1
60	ZX-22701		Positioning Shaft		1
61	ZX-S61		Brake Shoe		1
62	ZX-22702		Brake Shaft		1
63	ZX-22708		Connecting Plate		1
64	ZX-S64		Elastic Pin	5x25	1
65	ZX-22709		Connecting Shaft		1
66	ZX-S66		Stroke Switch		1
67	ZX-S67		Screw	M4x25	2
68	ZX-S68		Cylindrical End Set Screw.....	M5x10	1
69	ZX-22711		Butt Nail Support.....		1
70	ZX-S70		Pin	5n6x20	1
71	ZX-22715		Adjust Bolt		1
72	TS-1540061		Hex Nut	M8	1
73	ZX-S73		C-Clip	12	2
74	ZX-S74		Hex Cap Bolt.....	M8x35	1
75	ZX-S75		Taper Pin.....	5x20	2

Bed Assembly




Bed Assembly

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-01104A		Bed (for 1440/1640/1840ZX)		1
	ZX-01104B		Bed (for 1460/1660/1860ZX)		1
	ZX-01104C		Bed (for 1880ZX)		1
2	TS-1550101		Washer	B16	8
3	ZX-B3		Hex Cap Bolt	M16x50	8
4	ZX-01706		Rack		1
5	TS-1516041		Hex Socket Cap Screw (for 1440/1640/1840ZX). M10x35		10
			Hex Socket Cap Screw (for 1460/1660/1860ZX). M10x35		14
			Hex Socket Cap Screw (for 1880ZX). M10x35		18
6	ZX-B6		Taper Pin (for 1440/1640/1840ZX)	8x50	10
			Taper Pin (for 1460/1660/1860ZX)	8x50	14
			Taper Pin (for 1880ZX)	8x50	18
7	ZX-01706A		Rack (for 1440/1640/1840ZX)		4
			Rack (for 1460/1660/1860ZX)		6
			Rack (for 1880ZX)		8
8	ZX-01112		Saddle		1
9	TS-1551081		Lock Washer	12	4
10	TS-1517041		Hex Socket Cap Screw	M12x55	4
12	ZX-B12		Thread Taper Pin	12x70	2
13	TS-1491101		Hex Cap Bolt	M10x55	2
14	TS-1550071		Washer	M10	2
15	TS-1503021		Hex Socket Cap Screw	M6x10	6
16	TS-1550041		Washer	M6	6
17	ZX-01741A		Splash Guard (for 1440ZX)		1
	ZX-01741B		Splash Guard (for 1460ZX)		1
	ZX-01741C		Splash Guard (for 1640ZX)		1
	ZX-01741D		Splash Guard (for 1660ZX)		1
	ZX-01741E		Splash Guard (for 1840ZX)		1
	ZX-01741F		Splash Guard (for 1860ZX)		1
	ZX-01741G		Splash Guard (for 1880ZX)		1
18	ZX-B18		Shear Pin	5x35	2
19	ZX-01708A		Lead Screw (for 40" models, Serial # 010611ZX349 and lower)		1
	ZX-01708AN		New Lead Screw (for 40" models, Serial # 010618ZX350 and higher)		1
	ZX-01708B		Lead Screw (for 60" models, Serial # 010611ZX349 and lower)		1
	ZX-01708BN		New Lead Screw (for 60" models, Serial # 010618ZX350 and higher)		1
	ZX-01708C		Lead Screw (for 1880ZX, Serial # 010611ZX349 and lower)		1
	ZX-01708CN		New Lead Screw (for 1880ZX, Serial # 010618ZX350 and higher)		1
20	ZX-B20		Flat End Set Screw	M6x10	2
21	ZX-01109		Sleeve (serial # 010611ZX349 and lower)		1
	ZX-01109N		New Sleeve (serial # 010618ZX350 and higher)		1
22	ZX-1204		Double Row Spherical Ball Bearing	20x47x14	2
23	ZX-B23		C-Clip	20	2
24	ZX-01110		Bracket (serial # 010611ZX349 and lower)		1
	ZX-01110N		New Bracket (serial # 010618ZX350 and higher)		1
25	ZX-01111		Cover		1
26	TS-1514021		Hex Socket Cap Screw	M6x14	4
27	ZX-B27		Taper Pin	6x60	1
28	TS-1516061		Hex Socket Cap Screw	M10x50	1
29	ZX-B29		Oil Cup	10	2
30	TS-223991		Hex Socket Cap Screw	M10x100	1
31	ZX-B31		Taper Pin	6x100	1
32	ZX-01108		Sleeve (serial # 010611ZX349 and lower)		1
	ZX-01108N		New Sleeve (serial # 010618ZX350 and higher)		1
33	ZX-01709A		Feed Rod (for 40" models, serial # 010611ZX349 and lower)		1
	ZX-01709AN		New Feed Rod (for 40" models, serial # 010618ZX350 and higher)		1
	ZX-01709B		Feed Rod (for 60" models, serial # 010611ZX349 and lower)		1

Index	Part		Description	Size	Qty.
	ZX-01709BN		New Feed Rod (for 60" models, serial # 010618ZX350 and higher)		1
	ZX-01709C		Feed Rod (for 1880ZX, serial # 010611ZX349 and lower)		1
	ZX-01709CN		New Feed Rod (for 1880ZX, serial # 010618ZX350 and higher)		1
36	ZX-01707A		Control Rod (for 1440/1640/1840ZX)		1
	ZX-01707B		Control Rod (for 1460/1660/1860ZX)		1
	ZX-01707C		Control Rod (for 1880ZX)		1
37	TS-1540031		Nut	M5	1
40	ZX-06001C-2		Spacer		1
41	ZX-B41		Spring	1x75x25	3
42	ZX-06001C-1		Bracket		1
43	TS-1515011		Hex Socket Cap Screw	M8x16	2
44	ZX-B44		Lever		1
45	ZX-06001C-4		Long Lever Sleeve		1
46	ZX-B46		Hex Nut	M8	2
47	ZX-B47		Set Screw	M8x28	2
48	ZX-06001C-5		Direction Change Ring		1
49	ZX-B49		Pin	8n6x20	1
50	ZX-B50		Taper Pin	3x20	1
51	TS-1516061		Hex Socket Cap Screw	M10x48	2
52	ZX-05741		Threaded Tube		2
53	TS-1540081		Hex Nut	M12	2
59	ZX-01715C		Cover		1
60	ZX-B60		Cross Recessed Pan Head Screw	M6x18	4
61	TS-1482031		Hex Cap Bolt	M6x16	2
62	ZX-B62		Pin	2x15	2
63	ZX-01719		Rocker		1
90	C0632A-01301E		Switch Box		1
91	ZX-B91E		Hex Socket Cap Screw	M8x20	4
92	ZX-B92E		Screw	M6x16	1
93	Co632A-01705E		Bushing		1
94	ZX-B94E		Steel Ball	6	1
95	ZX-B95E		Spring		1
96	ZX-B96E		Screw	M8x16	1
97	Co632A-01504E		Switch Box Cover		1
98	ZX-B98E		Hex Socket Cap Screw	M5x10	4
99	Co632A-01503E		Plug		2
100	ZX-01706E		Positioning Sleeve		1
101	ZX-B101E		Screw	M5x8	1

Headstock Assembly I




Headstock Assembly I

Index	Part No.	Description	Size	Qty.
1	ZX-02306	Round Sign Plate		3
2	ZX-02122	Positioning Handle		1
3	ZX-H3	Flat End Set Screw	M10x12	1
4	ZX-H4	Spring	YI-1x8x25	1
5	ZX-H5	Steel Ball	8	1
6	ZX-H6	Countersunk Head Screw	M5x12	2
7	ZX-02743	Positioning Disc		1
8	ZX-02738	Shaft		1
9	ZX-H9	Taper Pin	5x55	1
10	ZX-H10	Half Circle Key	4x16	1
11	ZX-H11	Ring Seal	25x2.4	1
12	ZX-02116	Crank		1
13	TS-1523051	Set Screw	M6x16	1
14	ZX-H14	Pin	5n6x28	1
15	ZX-02302	Poking Block		1
16	ZX-02738C	Pin Block		1
17	TS-1523051	Set Screw	M6x16	1
18	ZX-02114	Crank		1
19	ZX-H11	Ring Seal	25x2.4	1
20	ZX-H20	Pin	5x30	1
21	ZX-02734	Shaft		1
22	ZX-H10	Half Circle Key	4x16	1
23	ZX-H5	Steel Ball	8	1
24	ZX-H4	Spring	YI-1x8x25	1
25	ZX-H3	Flat End Set Screw	M10x12	1
26	ZX-02733	Left Positioning Disc		1
27	ZX-H6	Countersunk Head Screw	M5x12	2
28	ZX-02113	Left Lever Support		1
29	ZX-02741	Handle		1
30	ZX-02732	Cover		1
31	ZX-H6	Countersunk Head Screw	M5x12	1
32	ZX-H6	Countersunk Head Screw	M5x12	1
33	ZX-02732	Cover		1
34	ZX-02119	Right Lever Support		1
35	ZX-H3	Flat End Set Screw	M10x12	1
36	ZX-H4	Spring	YI-1x8x25	1
37	ZX-H5	Steel Ball	8	1
38	ZX-02728	Right Positioning Disc		1
39	ZX-02741	Handle		1
40	ZX-H6	Countersunk Head Screw	M5x12	2
41	ZX-H10	Half Circle Key	4x16	1
42	ZX-02727	Shaft		1
43	ZX-H10	Half Circle Key	4x16	1
44	ZX-H11	Ring Seal	25x2.4	1
45	ZX-02730	Gear	1.5m36T	1
46	TS-1523051	Set Screw	M6x16	1
47	ZX-02738C	Pin Block		1
48	TS-1523051	Set Screw	M6x16	1
49	ZX-02111	Crank		1
50	ZX-H10	Half Circle Key	4x16	1
51	ZX-02731/1	Control Shaft		1
52	ZX-H 10	Half Circle Key	4x16	1
53	ZX-H11	Ring Seal	25x2.4	1
54	ZX-H54	Taper End Set Screw	M6x16	1
55	ZX-02732/2	Gear	1.5m36T	1
56	ZX-H56	Ring Seal	40x3.1	1

Index	Part			
No.	No.	Description	Size	Qty.
57	ZX-02110	Bushing		1
58	ZX-02729	Cover		1
59	ZX-H59	Pin	3n6x10	1
60	ZX-H6	Countersunk Head Screw	M5x12	1
61	ZX-H61	Countersunk Head Screw	M8x12	1
62	ZX-H62	Flat End Set Screw	M8x12	1
63	ZX-02115	Bearing Support		1
64	ZX-H64	Ring Seal	40x3.1	1
65	ZX-02115	Left Fork		1
66	ZX-H66	Flat End Set Screw	M6x10	1
67	ZX-02120A/2	Bushing		1
68	ZX-H68	Taper Pin	6x35	1
69	ZX-02736	Control Shaft		1
70	ZX-02112	Right Fork		1
71	ZX-H66	Flat End Set Screw	M6x10	1
72	ZX-02120A/2	Bushing		1
73	ZX-H73	Ring Seal	30x3.1	1
74	ZX-02735	Blocking Piece		1
75	ZX-H61	Countersunk Head Screw	M8x12	1
76	ZX-02744	Adjusting Screw		1
77	ZX-H77	Taper Pin	8x40	1
78	ZX-H77	Taper Pin	8x40	1
79	ZX-92124	Adjusting Block		1
80	ZX-H80	Hex Cap Bolt	M12x50	1
81	ZX-02744	Adjusting Screw		1
82	ZX-02736C	Positioning Pin		1
83	ZX-H83	Oil Sight Glass		1
84	ZX-H84	Washer	A16	2
85	ZX-H85	Hex Socket Cap Screw	M16x50	2
86	ZX-02301A	Label (for 1440ZX)		1
	ZX-02301B	Label (for 1460ZX)		1
	ZX-02301C	Label (for 1640ZX)		1
	ZX-02301D	Label (for 1660ZX)		1
	ZX-02301E	Label (for 1840ZX)		1
	ZX-02301F	Label (for 1860ZX)		1
	ZX-02301G	Label (for 1880ZX)		1
87	TS-1504071	Hex Socket Cap Screw	M8x35	4
88	ZX-H88	Countersunk Head Screw	M16x25	1
89	ZX-02117	Top Cover		1
90	ZX-H90	Hex Cap Bolt		2
91	ZX-H91	Washer	A16	2
92	ZX-02505	Paper Gasket		1
93	ZX-H93	Cross Recessed Pan Head Screw	M3x6	7
94	ZX-H94N	Pin	4n6x15	2

Headstock Assembly II




Headstock Assembly II

Index	Part	Description	Size	Qty.
No.	No.			
95	ZX-02107	Pulley		1
96	TS-1514041	Hex Socket Cap Screw	M6x25	4
97	ZX-02106	Bearing Cover		1
98	ZX-02506	Gasket.....		1
99	ZX-H99	Ring Seal.....	32x52	1
100	BB-6207	Ball Bearing.....	35x72x17	1
101	BB-6207	Ball Bearing.....	35x72x17	1
102	ZX-H102	Sleeve	30x10	1
103	TS-1515031	Hex Socket Cap Screw	M8x25	6
104	ZX-02105	Bearing Support		1
105	ZX-02502	Gasket.....		1
106	ZX-H106	Flat Key	10x8x35	1
107	ZX-02709	Shaft.....		1
108	ZX-02754X	Gear (for 14" models).....	2.5m52T	1
	ZX-02754X/6P	Gear (for 16"/18" models)	2.5m61T	1
109	ZX-02753X	Gear (for 14" models).....	2.5m28T	1
	ZX-02753X/6P	Gear (for 16"/18" models)	2.5m32T	1
110	ZX-02752X	Gear	2.5m18T	1
111	ZX-02751X	Gear (for 14"models).....	2.5m41T	1
	ZX-02751X/6P	Gear (for 16"/18" models)	2.5m47T	1
112	ZX-H112	Sleeve		1
113	BB6305/P6	Ball Bearing.....	25x62x17	1
114	ZX-H114	Shaft End Lock Ring	32	1
115	ZX-H115	Countersunk Head Screw	M6x20	1
116	ZX-H59	Pin	3n6x10	1
117	ZX-H117	Ring Seal.....	60x3.1	1
118	ZX-02104	Blocking Flange		1
119	TS-1514021	Hex Socket Cap Screw	M6x15	3
120	TS-1514021	Hex Socket Cap Screw	M6x15	3
121	ZX-02103	Blocking Flange		1
122	ZX-H117	Ring Seal.....	60x3.1	1
123	BB-6305	Ball Bearing.....	25x62x17	1
124	ZX-H124	Sleeve	62x6	1
125	BB-6305	Ball Bearing.....	25x62x17	1
126	ZX-H126	Circle Clip For Shaft.....	35	1
127	ZX-02705	Gear	3m19T	1
128	ZX-H128	Flat Key	8x7x50	2
129	ZX-02706	Gear	3m67T	1
130	ZX-02707	Gear	3m59T	1
131	ZX-H62	Flat End Set Screw	M8x12	1
132	ZX-02708	Shaft.....		1
133	ZX-H133	C-Clip	35	1
134	ZX-H134	Sleeve	35x8	1
135	BB-6007	Ball Bearing.....	35x62x14	1
136	ZX-H136	Sleeve	35x8	1
137	ZX-H133	C-Clip	35	1
138	ZX-02756	Gear (for 14" models).....	2.5m42T	1
	ZX-02756/6P	Gear (for 16"/18" models)	2.5m36T	1
139	ZX-H139	Pin	8n6x25	1
140	ZX-02757	Gear (for 14" models).....	2.5m65T	1
	ZX-02757/6P	Gear (for 16"/18" models)	2.5m65T	1
141	ZX-02758	Gear (for 14" models).....	2.5m55T	1
	ZX-02758/6P	Gear (for 16"/18" models)	2.5m51T	1
142	ZX-H142	Flat Key	10x6x60	2
143	ZX-H143	Flat Head Set Screw	M8x12	2
144	ZX-02755X	Gear (for 14" models).....	2.5m31T	1

Index	Part	Description	Size	Qty.
No.	No.			
	ZX-02755X/6P	Gear (for 16"/18" models)	2.5m22T	1
145	ZX-H133	C-Clip	35	1
146	BB-6305	Ball Bearing	25x62x17	1
147	ZX-H147	Pushing Disc	62	1
148	ZX-02109C	Cover		1
149	TS-1514021	Hex Socket Cap Screw	M6x15	3
150	ZX-H150	Set Screw	M12x65	1
151	ZX-H151	Hex Nut	M12	1
187	ZX-H187	Ring Seal	35x3.1	1
188	ZX-02714	Shaft		1
189	ZX-02716	Double Gear	2m48T	1
190	ZX-02303	Copper Sleeve		1
191	ZX-02734C	Positioning Sleeve		1
192	TS-1523031	Set Screw	M6x10	1
193	TS-1524041	Set Screw	M8x15	1
194	ZX-02733C	Blocking Piece		1
195	ZX-02718	Taper End Set Screw		1
196	ZX-02114C	Sleeve		1
197	BB-6203	Ball Bearing	17x40x12	1
198	ZX-H198	C-Clip	28	1
199	ZX-02717	Gear	2m65T	1
200	ZX-02715	Shaft		1
201	ZX-H201	Flat Key	5x5x1	1
202	ZX-H198	C-Clip	28	1
203	ZX-02722C	Sleeve		1
204	ZX-02301	Oil Bushing		1
205	ZX-08106A	Bracket (for Shaft V, Vb) (for 14"/16" models)		1
	ZX-08106B	Bracket (for Shaft V, Vb) (for 18" models)		1
206	ZX-H77	Taper Pin	8x40	1
207	TS-1516021	Hex Socket Cap Screw	M10x25	1
208	TNMP08706A(N)	Gear (for 14"/16" models)	3.5m16T	1
	TNMP08706B(N)	Gear (for 18" models)	4m16T	1
209	ZX-02724C	Washer		1
210	ZX-H59	Pin	3n6x10	1
211	ZX-H211	Countersunk Head Screw	M5x16	1
221	VB-A78	V-Belt (for 14" models)	A-78	4
	VB-A79	V-Belt (for 16" models)	A-79	4
	VB-A81	V-Belt (for 18" models)	A-81	4
233	ZX-02506	Paper Gasket		2
234	ZX-H234	Set Screw	M8x6	2
235	ZX-02743N	Clamping Round Nut		1
236	ZX-H236	Pin	8x30	2


Headstock Assembly III



Headstock Assembly III

Index	Part		Description	Size	Qty.
No.	No.				
152	ZX-02704		Spindle		1
153	ZX-H153		Flat Key	10x8x40	1
154	ZX-H154		Flat Key	10x8x50	1
155	ZX-H155		Flat Key	12x8x50	1
156	ZX-H156		Flat Key	14x9x50	1
157	ZX-02701		Cam Lock		6
158	ZX-H158		Spring	1x8x25	6
159	ZX-02703		Cam Positioning Screw		6
160	TS-1516031		Hex Socket Cap Screw	M10x28	6
161	ZX-02102		Bearing Front Cover		1
162	ZX-02501		Gasket		1
163	ZX-02702		Oil Splashing Ring		1
164	NN3024/P5		Taper Roller Bearing	120x180x46	1
165	ZX-02726		Lining		1
168	ZX-02725A		Round Nut w/Screw		1
169	ZX-02723		Gear	3m98T	1
170	ZX-02722		Gear	3m50T	1
171	ZX-02721		Gear	3m58T	1
172	ZX-02720A		Round Nut w/Screw		1
175	ZX-02710		Gear	2m65T	1
176	51120/P5		Thrust Bearing	100x135x25	1
179	BB-7020AC/P5		Angular Bearing	100x150x24	1
184	ZX-02713A		Round Nut w/Screw		1
212	ZX-H212		Drain Plug (14" models, Serial #001204ZX258 and lower)		1
			Drain Plug (16" models, Serial #010312ZX293 and lower, also includes Serial #010319ZX298 & 299)		1
			Drain Plug (18" models, Serial #010416ZX313 and lower)		1
212	ZX-H212A		Drain plug (14" models, Serial #010105ZX263 and higher)		1
			Drain plug (16" models, Serial #010319ZX294 and higher, except for Serial #010319ZX298 & 299)		1
			Drain plug (18" models, Serial #010514ZX323 and higher)		1
213	ZX-02101A		Headstock Casting (14" models, Serial #001204ZX258 and lower)		1
	ZX-02101AN		Headstock Casting (14" models, Serial #010105ZX263 and higher)		1
	ZX-02101B		Headstock Casting (16" models, Serial #010312ZX293 and lower, also includes Serial #010319ZX298 & 299)		1
	ZX-02101BN		Headstock Casting (16" models, Serial #010319ZX294 and higher, except for Serial #010319ZX298 & 299)		1
	ZX-02101C		Headstock Casting (18" models, Serial #010416ZX313 and lower)		1
	ZX-02101CN		Headstock Casting (18" models, Serial #010514ZX323 and higher)		1
224	ZX-G38-3A		Screw		1
226	ZX-H226		Hex Socket Cap Screw	M8x28	9
227	ZX-02502F		Gasket		1
228	ZX-02108F		Bearing Support		1
229	ZX-02711F		Sleeve		1
230	ZX-02510F		Gasket		1
231	ZX-02761F		Bearing Back Cover		1
232	ZX-H232		Screw	M5x10	6


Headstock Assembly IV



Headstock Assembly IV

Index	Part		Description	Size	Qty.
No.	No.				
214	ZX-08302A		Back Cover (for 14" models)		1
	ZX-08302B		Back Cover (for 16" models)		1
	ZX-08302C		Back Cover (for 18" models)		1
215	ZX-08114A		Rear Side plate (for 14" models)		1
	ZX-08114B		Rear Side plate (for 16" models)		1
	ZX-08114C		Rear Side plate (for 18" models)		1
216	ZX-08113A		Front Side plate (for 14" models)		1
	ZX-08113B		Front Side plate (for 16" models)		1
	ZX-08113C		Front Side plate (for 18" models)		1
217	TS-1515031		Hex Socket Cap Screw	M8x25	4
218	ZX-H218		Taper Pin	6x25	4
219	TS-1514031		Hex Socket Cap Screw	M6x20	8
220	TS-1514021		Hex Socket Cap Screw	M6x15	3
222	ZX-08712		Upper Hinge		2
223	ZX-H223		Pin	6n6x40	2
225	ZX-08711		Lower Hinge		2


Change Gear Box Assembly I



Change Gear Box Assembly I

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-08101		Change Gear Box Casting		1
2	ZX-08108		Front Cover		1
5	ZX-05104C		Hand Wheel		1
6	ZX-05301C		Sign Plate.....		1
7	ZX-08708		Positioning Disc		1
8	ZX-08505		Gasket.....		1
9	ZX-08111		Crank.....		1
10	ZX-08705		Connecting Rod		1
11	ZX-08304		Sliding Block.....		1
12	ZX-05103C		Cam.....		1
13	ZX-05702C		Roller.....		2
14	ZX-08109		Crank.....		1
15	ZX-08110		Bushing		1
16	ZX-08704		Rotating Shaft		1
17	ZX-08703		Connecting Rod		1
18	ZX-08304		Sliding Block.....		1
26	ZX-C26		Cross Head Screw	M4x12	3
28	TS-1515031		Hex Socket Cap Screw	M8x25	4
29	TS-1516051		Hex Socket Cap Screw	M10x40	2
30	TS-1525021		Set Screw.....	M10x12	1
31	ZX-C31		Flat Head Set Screw	M6x8	1
33	ZX-C33		Taper Pin	4x45	1
34	ZX-C34		Taper Pin	6x30	2
35	ZX-C35		Taper Pin	6x50	1
36	ZX-C36		Pin	10m6x40	2
37	ZX-C37		Pin	10m6x50	2
38	ZX-H5		Steel Ball	8	1
42	ZX-C42		Spring	1x8x30	1


Change Gear Box Assembly II



Change Gear Box Assembly II

Index	Part		Description	Size	Qty.
No.	No.				
3	ZX-08104		End Cover		4
4	ZX-08103		Bearing Support		1
19	ZX-08107		Gear	3m36T	1
20	ZX-08105		Double Gear.....	3.75m28T/3m30T	1
21	ZX-08702		Shaft.....		1
22	ZX-08701		Shaft.....		1
23	ZX-08710		Gear	3.75m27T.....	1
24	ZX-08709		Gear	3m41T.....	1
25	ZX-08102		Double Gear.....	3.75m30T/3m29T	1
27	ZX-C27		Slotted Cheese Head Screw.....	M5x12	15
32	ZX-C32		Flat Head Set Screw	M10x12	1
39	BB-6203		Ball Bearing.....	17x40x12	5
40	ZX-C40		C-Clip	25	4
41	ZX-C41		C-Clip	40	1
43	ZX-C43		Oil Cup	8	1
44	TNMP08108		Washer		1
45	TNMP08102		Splinted Sleeve		1
46	TNMP08504		Gear	3m41T	1
47	TNMP08501A		Gear (for 14"/16" models)	3.5m36T	1
	TNMP08501B		Gear (for 18" models).....	4m36T	1
48	ZX-05502C		Oil Bushing.....		1
49	ZX-08707		Shaft Vb		1
50	ZX-C50		Flat Head Set Screw	M8x10	1

Quick Change Gear Box I




Quick Change Gear Box I

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-05153A		Upper Cover.....		1
2	TS-1514051		Hex Socket Cap Screw	M6x30	2
6	TS-1515011		Hex Socket Cap Screw	M8x16	10
7	ZX-05109		Rear Cover.....		1
8	ZX-05502		Gasket.....		1
9	ZX-Q09		Countersunk Head Screw	M10x18	1
10	ZX-05101		Feedbox Casting.....		1
11	ZX-05501		Gasket.....		1
12	ZX-05108		Flange		1
13	TS-1515011		Hex Socket Cap Screw	M8x16	6
14	ZX-05151		Extending Plate		1
15	TS-1503131		Hex Socket Cap Screw	M6x60	4
19	ZX-Q19		Hex Cap Bolt.....	M10x1	1
20	TS-1491061		Hex Cap Bolt.....	M10x40	2
21	ZX-H68		Taper Pin.....	6x35	2
22	ZX-05738		Control Shaft		1
23	ZX-05739		Sliding Key		3
24	ZX-05128		Sliding Sleeve		3
25	ZX-Q25		Flat Head Set Screw	M5x8	4
26	ZX-05125		Right Fork.....		1
27	ZX-05126		Middle Fork		1
28	ZX-05127		Left Fork		1
29	ZX-Q29		Ring Seal.....	32x3.1	1
30	ZX-Q30		Taper Pin	4x25	2
31	ZX-05129		Cover.....		1
32	ZX-Q32		Pin	5n6x15	1
33	ZX-Q33		Cheese Head Screw	M5x16	3
34	ZX-05122		Cam.....		1
35	ZX-05728		Rolling Sleeve		5
36	ZX-05729		Poking Key		3
37	ZX-05123		Crank.....		1
38	ZX-Q38		Pin	8n6x32	5
39	ZX-Q39		Pin	6n6x20	5
40	ZX-05124		Crank.....		1
41	ZX-05111		Sleeve		1
42	ZX-05726		Lever Shaft.....		1
43	ZX-Q43		Taper Pin	4x32	2
44	ZX-Q44		Taper Pin	4x65	1
45	ZX-05121		Crank.....		1
46	ZX-05118		Cam.....		1
47	ZX-05120		Crank.....		1
48	ZX-05116		Fork		1
49	ZX-Q49		Pin	8n6x18	2
50	ZX-05117		Sleeve		1
51	ZX-05737		Lever Shaft.....		1
52	ZX-C33		Taper Pin	4x45	2
53	ZX-05115		Fork		1
54	ZX-05119		Crank.....		1
55	ZX-05735		Pin		1
56	ZX-05112		Fork		1
57	ZX-05113		Crank.....		1
58	ZX-05730		Small Shaft.....		1
59	ZX-05731		Big Gear	1m44T	1
60	ZX-05732		Small Gear	1m22T	1

Index	Part			
No.	No.	Description	Size	Qty.
61	ZX-05114	Sleeve		1
62	ZX-05734	Lever Shaft.....		1
63	ZX-05503	Gasket.....		1
64	ZX-05110	Front Cover		1
65	TS-1516011	Hex Socket Cap Screw	M10x20	5
66	ZX-Q66	Taper Pin	5x35	6
67	ZX-05303A	Sign Plate.....		1
68	ZX-Q68	Cross Head Screw	M3x6	7
69	ZX-Q69	Oil Sight Glass	20	1
70	ZX-05727	Positioning Disc		1
71	ZX-Q71	Countersunk Head Screw	M4x12	9
72	ZX-05740	Lever		1
73	ZX-05130A	Lever Support.....		1
74	ZX-05301	Sign Disc		3
75	ZX-H5	Steel Ball	8	3
76	ZX-Q76	Compression Spring.....	YZ-1x8x25	3
77	ZX-H3	Flat End Set Screw	M10x12	3
78	ZX-05736	Positioning Disc		1
79	ZX-05140	Hand Wheel		2
80	ZX-05733	Positioning Disc		1


Quick Change Gear Box II



Quick Change Gear Box II

Index	Part		Description	Size	Qty.
No.	No.				
81	ZX-05104		Middle Bearing Support		2
82	ZX-Q82		Taper End Set Screw	M10x16	2
83	ZX-B23		C-Clip	20	3
84	ZX-Q84		C-Clip	42	5
85	BB-6004		Single Row Radial Ball Bearing	20x42x12	5
86	ZX-05721		Shaft.....		1
87	ZX-05722		Double Gear.....	2m26T/2m52T	1
88	ZX-Q88		Iron Wire.....	1x190	2
89	TS-1524051		Set Screw.....	M8x20	2
90	ZX-05720		Positioning Sleeve		1
91	ZX-05719		Gear	2.25m28T	1
92	ZX-05718		Double Gear.....	2m26T/2m28T	1
93	ZX-05717		Gear	3.5m20T	1
94	ZX-05716		Double Gear.....	3.5m18T/3.5m19T	1
95	ZX-05715		Gear	3.25m22T	1
96	ZX-05714		Double Gear.....	3.25m24T/3.25m23T	1
97	BB-6205		Single Row Radial Ball Bearing	25x52x15	2
98	ZX-C40		C-Clip	25	3
99	ZX-05125		Shaft End Cover.....		1
100	TS-1515011		Hex Socket Cap Screw	M8x18	2
101	ZX-05704		Spacer.....		1
102	ZX-05705		Double Gear.....	2m52T/2m26T	1
103	ZX-05502C		Oil Bushing.....		3
104	ZX-05105		Sleeve		2
105	ZX-05707		Double Gear.....	2m39T/2m26T	1
106	ZX-Q106		Iron Wire.....	1x160	3
107	TS-1524031		Set Screw.....	M8x12	3
108	ZX-05714C		Fixed Bushing		1
109	ZX-05710		Shaft.....		1
110	ZX-05709		Double Gear.....	2m48T/2.25m42T	1
111	ZX-05711		Sliding Gear	3.5m24T	1
112	ZX-05712		Sliding Gear	3.25m24T	1
113	ZX-05713		Sleeve		1
114	ZX-G51-1		Spacer	32	1
115	ZX-05106		Bearing Support		1
116	TS-1515031		Hex Socket Cap Screw	M8x25	3
141	ZX-05504		Gasket.....		1
142	ZX-05505		Gasket.....		1


Quick Change Gear Box III



Quick Change Gear Box III

Index	Part	Description	Size	Qty.
No.	No.			
66	ZX-Q66.....	Taper Pin	5x35	6
83	ZX-Q83.....	C-Clip	20	3
84	ZX-Q84.....	C-Clip	42	5
85	BB104.....	Single Row Radial Ball Bearing	20x42x12	5
98	ZX-Q98.....	C-Clip	25	3
106	ZX-Q106.....	Iron Wire.....	1x160	3
107	TS-1524031	Set Screw.....	M8x12	3
117	ZX-05113C	Shaft Coupling.....		2
118.....	ZX-Q118.....	Round Nut	M24x1.5	2
119.....	TS-1503021	Hex Socket Cap Screw	M6x10	2
120	ZX-05114.....	Cover.....		1
121	BB-51105.....	Thrust Bearing	25x42x11	2
122	ZX-Q122.....	Spacer	25	2
123	BB-6305	Ball Bearing.....	25x62x17	1
124	ZX-05725	Shaft.....		1
125	ZX-Q125.....	Key	8x7x50	1
126	ZX-05724	Double Gear.....	2.25m35T/2.25m36T ..	1
127	ZX-05723	Gear	2.5m36T	1
128	ZX-05107	Sleeve		2
129	BB-6005	Ball Bearing.....	25x47x12	1
130	TS-1525021	Set Screw.....	M10x12	2
131	ZX-05103	Bearing Support		1
132	ZX-05701	Shaft.....		1
133	ZX-Q133.....	Half Circle Key	6x22	1
134	ZX-05703	Gear	2.5m36T	1
135	ZX-05102	Bearing Support		1
136	ZX-05702	Double Gear.....	2.5m24T/2.25m35T ..	1
137	ZX-05708	Shaft.....		1
138	ZX-05706	Triple Gear	2m39T/2m52T/2m26T	1
139	BB-6203	Ball Bearing.....	17x40x12	1
140	ZX-Q140.....	C-Clip	17	1

Apron Assembly I




Apron Assembly I

Index No.	Part No.	Description	Size	Qty.
1	TL06101	Apron Casting		1
2	TL06103	Bottom Cover		1
3	TS-1540072	Hex Nut	M10.....	1
4	ZX-A04	Flat Head Set Screw	M10x70	1
5	TL06502	Cushion Cap		1
6	ZX-A06	Pin	6n6x16	2
7	ZX-A07	Tensile Spring	Y11.2x9x50	1
8	TL06734	Lever		1
9	ZX-A09	Pin	8n6x30	1
10	ZX-A10	Pin	6n6x18	1
11	TL06701-A	Pushing Rod		1
12	ZX-A12	Oil Seal	15x2.4	1
13	BB60016	Ball Bearing	6x17x6	1
14	ZX-A06	Pin	6n6x16	1
15	ZX-A15	Drain Plug	Z 1/4"	1
16	ZX-B34	Taper Pin	5x30	2
17	TS-1504041	Hex Socket Cap Screw	M8x20	6
18	TL06501	Gasket		1
19	TL06307	Sign Plate		1
20	TL06716	Lever		1
21	ZX-06122	Lever Support		1
22	ZX-B27	Taper Pin	6x60	1
23	TL06717	Half Nut Shaft		1
24	TL06111	Positioning Block		1
25	ZX-A25	Thread Tail Taper Pin	6x25	1
26	TS-1523031	Set Screw	M6x10	1
27	ZX-06733	Half Nut Control Plate		1
28	ZX-A28	Taper Pin	6x55	1
29	ZX-06732	Pin		2
30	ZX-06302	Half Nut (serial # 010611ZX349 and lower)		1
	ZX-06302N	New Half Nut (serial # 010618ZX350 and higher)		1
31	TS-1540072	Hex Nut	M10	1
32	ZX-A32	Cylindrical End Set Screw	M10x60	1
33	ZX-06121	Gib		1
34	ZX-06731	Cylindrical End Set Screw		3
35	TS-1540061	Hex Nut	M8	3
36	ZX-A36	Set Screw	M8x32	1
37	ZX-A37	Oil Sight Glass	20	1
69	TL06727	Gear (serial # 010611ZX349 and lower)	2m25T	1
	TL06727N	New Gear (serial # 010618ZX350 and higher)	2m25T	1
70	TL06728	Sliding Key		2
71	TL06121	Spacer (serial # 010611ZX349 and lower)		2
	TL06121N	New Spacer (serial # 010618ZX350 and higher)		2
72	TL06304	Positioning Sleeve (serial # 010611ZX349 and lower)		2
	TL06304N	New Positioning Sleeve (serial # 010618ZX350 and higher)		2
73	ZX-A73	Ring Seal For Rotating	3x55	2
74	ZX-A74	Oil Seal	35x3.1	1
75	TL06729	Sleeve (serial # 010611ZX349 and lower)		1
	TL06729N	New Sleeve (serial # 010618ZX350 and higher)		1
122	TL06302	Sign Plate		1
123	TL06730	Shaft		1
124	BB-51104	Thrust Bearing		2
125	TL06305	Sleeve		2
126	TL06726	Worm (serial # 010611ZX349 and lower)		1
	TL06726N	New Worm (serial # 010618ZX350 and higher)		1
127	TL06122	Worm Support (serial # 010611ZX349 and lower)		1

Index	Part			
No.	No.	Description	Size	Qty.
TL06122N	New Worm Support (serial # 010618ZX350 and higher).....		1
128	TL06720	Control Plate		1
129	TS-1514031	Hex Socket Cap Screw	M6x20	4
130	ZX-A130	Taper Pin	4x20	1
131	TS-1524031	Set Screw.....	M8x12	2
132	ZX-A132	Screw	M8x25	2
133	ZX-A133	Cylindrical Tensile Spring	LI-1.6x10x58	1
134	TL06503	Gasket.....		1
135	TL06114	Back Cover.....		1
136	TS-1514011	Hex Socket Cap Screw	M6x12	5
137	ZX-A137	Set Screw.....	M8x30	2
138	ZX-A138	Iron Wire.....	1x50	2
139	ZX-A139	Oil Conducting Cord.....	3x100	2
140	ZX-A140	Screw	M10x40	1
158	TS-1540041	Hex Nut	M6	1
159	TL06124	Bracket.....		1
160	ZX-A160	Taper Pin	5x25	2
161	TL06308	Bracket.....		1
162	TS-1503041	Hex Socket Cap Screw	M6x16	1

Apron Assembly II




Apron Assembly II

Index	Part		Description	Size	Qty.
No.	No.				
38	ZX-B23		C-Clip	20	1
39	BB-6204		Ball Bearing.....	20x47x14	1
40	TL06705		Gear	2m65T	1
41	ZX-A41		Taper Pin	6x40	1
42	ZX-C40		C-Clip	25	1
43	ZX-06127		Bearing Support (serial # 010611ZX349 and lower).....		1
	ZX-06127N		New Bearing Support (serial # 010618ZX350 and higher).....		1
44	TS-1504041		Hex Socket Cap Screw	M8x18	3
45	BB-6205Z		Ball Bearing	25x52x15	1
46	ZX-A46		C-Clip	52	1
47	TL06704		Shaft (serial # 010611ZX349 and lower).....	2m14T	1
	TL06704N		New Shaft (serial # 010618ZX350 and higher).....	2m14T	1
48	TL06706		Hand Wheel Shaft.....	2mx15T	1
49	ZX-H10		Half Circle Key	4x16	1
50	ZX-A50		Oil Cup	8	1
51	TL06104		Lever Support.....		1
52	TS-1514031		Hex Socket Cap Screw	M6x18	3
53	TL06105		Dial Support		1
54	ZX-A54		Cross Head Screw	M5x12	3
55	TL06732		Dial		1
56	TL06107		Hand Wheel		1
57	ZX-06710		Shaft Driven Lever		1
58	TL06709		Shaft Cover		1
59	ZX-A54		Cross Head Screw	M5x12	1
60	TL06708		Screw		1
61	TL06707		Pin		1
62	TL06112		End Cover		1
63	TS-1514011		Hex Socket Cap Screw	M6x12	3
64	TL06733		T Shaped Flat Key		1
65	TL06115		Flange Sleeve		1
66	TS-1514011		Hex Socket Cap Screw	M6x12	3
67	ZX-A67		Flat End Set Screw	M6x30	1
68	TS-1540041		Hex Nut	M6	1
76	TL06109		Flange		1
77	TS-1514011		Hex Socket Cap Screw	M6x12	3
78	TL06303		Sign Plate		1
79	TL06714		Adjusting Screw		1
80	ZX-A80		Oil Seal.....	8x1.9	1
81	BB-7203		Ball Bearing.....	17x40x12	1
82	TL06713		Shaft.....		1
83	TL06715		Adjusting Rod		1
84	ZX-H10		Half Circle Key	4x16	1
85	TL06712		Spring Cover		1
86	ZX-A86		Spring	Y1-5x35x50	1
87	TL06718		Gear	2m28T	1
88	TL06113		Helical Gear	2.5m40T	1
89	BB7006/P6		Ball Bearing	30x55x13	1
90	TS-1523031		Set Screw	M6x10	1
91	ZX-A25		Thread Tail Taper Pin	6x25	1
92	TL06110		Fork		1
93	ZX-06721E		Control Rod		1
94	ZX-06116E		Lever Support.....		1
96	ZX-H5		Steel ball.....	8	1
97	ZX-A97		Spring	Y1-1x7x25	1
98	ZX-A98		Flat Head Set Screw	M10x16	1

Index	Part			
No.	No.	Description	Size	Qty.
100	ZX-A100	Cross Head Screw	M5x10	3
101	TL06117E	Cover		1
104	ZX-A104	Flat Head Set Screw	M4x8	1
105	TL06301	Sleeve		1
106	TL06710	Gear	2m21T/2m57T	1
107	ZX-A107	Pin	6n6x8	1
108	TL06711	Shaft		1
109	TL06108	End Cover		1
110	TS-1514011	Hex Socket Cap Screw	M6x12	3
111	TL06723	Control Shaft		1
112	TL06725	Pin		1
113	TL06724	Control Block		1
114	ZX-A114	Oil Seal	20x2.4	1
115	ZX-A115	Oil Seal	50x3.1	1
116	TL06119	Lever Flange		1
117	TS-1514011	Hex Socket Cap Screw	M6x12	3
118	TL06118	Lever Support		1
119	TL06307	Sign Plate		1
120	TL06716	Lever		1
121	ZX-B27	Taper Pin	6x60	1
163	ZX-A163E	Cross Head Screw	M6x18	4
164	ZX-A164E	Hexagon socket cap head Screw	M4x6	1
165	ZX-06125E	Lever		1
167	ZX-06737E	Lever		1
168	ZX-06736E	Washer		1
169	ZX-A169E	Cross Head Screw	M5x10	1
170	ZX-06310E	Sign Plate		1


Apron Assembly III



Apron Assembly III

Index	Part		Description	Size	Qty.
No.	No.				
141	ZX-A141		Half Round Head Screw	M6x18	1
142	ZX-11704		Washer		1
143	ZX-11301		Dial		1
144	ZX-11105		Adjusting Washer		1
145	ZX-11701		Shaft		1
146	ZX-H10		Half Circle Key	4x16	1
147	ZX-A147		Half Round Head Screw	M3x6	2
148	ZX-11303		Positioning Sign Plate		1
149	ZX-11703		Adjusting Washer		1
150	ZX-11101		Casting		1
151	ZX-A151		Acorn Nut	M12	1
153	ZX-11102E		Helical Gear	2m15T	1
154	TS-1550071		Flat Washer	M10	1
155	TS-1540072		Hex Nut	M10	1
156	ZX-11702		Bolt		1
157	ZX-A157		Oil Cup	8	2

Carriage Assembly




Carriage Assembly

Index	Part No.	Description	Size	Qty.
1	ZX-04101A	Saddle Casting.....		1
2	ZX-04505	Wipe Plate.....		1
3	ZX-04504	Wipe Plate.....		1
4	ZX-H211	Countersunk Head Screw.....	M5x16	11
5	ZX-04724	Clamping Block.....		2
6	ZX-04113	Lining Plate		2
7	TS-1516031	Hex Socket Cap Screw	M10x30	4
8	TS-1540061	Hex Nut	M8	4
9	ZX-CA09	Square Set Screw	M8x20	4
10	ZX-04506	Wipe Plate.....		1
11	TS-1505071	Hex Socket Cap Screw	M10x45	8
12	ZX-CA12	Square Cap Bolt.....	M12x60	1
13	ZX-CA13	Taper Pin	8x60	2
14	ZX-04729	Clamping Block.....		1
15	ZX-04730	Locking Plate.....		1
16	ZX-CA16	Pin	4n6x12	1
17	ZX-04772	Blocking Piece		1
18	ZX-CA18	Fitting Joint Seal	A4	8
19	ZX-CA19	Hollowed Bolt	A4	8
20	ZX-CA20	Copper Tube		4
21	ZX-04782	Manual Oil Pump Casting		1
22	ZX-04781A	In Valve		1
23	ZX-CA23	Oil Ring	15x2.4	1
24	ZX-04784	Piston		1
25	ZX-CA25	Spring	1.2x14x65	1
26	ZX-04785	Oil Pump Cover.....		1
27	TS-1513031	Hex Socket Cap Screw	M5x16	2
28	ZX-04783	Lever		1
29	ZX-CA29	Countersunk Head Screw	M4x16	3
30	ZX-A130	Taper Pin	4x20	1
31	ZX-04781B	Out Valve.....		1
32	ZX-04716	Chip Guard.....		1
33	ZX-CA33	Slotted Cheese Head Screw.....	M5x20	4
34	ZX-04780	Oil Distributor		1
35	ZX-04740	Clamping Block		1
36	ZX-04750	Oil Cap		1
37	ZX-04301	Oil Indicator Cap		1
38	ZX-04721	Lever		1
39	ZX-CA39	Cross Head Screw	M5x16	1
40	ZX-04720	Handle		1
41	ZX-04769	Sleeve		1
42	ZX-CA42	Round Nut	M12x1.25	4
43	ZX-04719	Lining		1
44	ZX-04770	Disc Spring		1
45	ZX-04108	Flat Pan		1
46	ZX-04790	Pushing Rod		1
47	ZX-04789	Screw		1
48	ZX-04717	Dial		1
49	BB-51102	Thrust Bearing	15x28x9	2
50	ZX-04111	Sleeve		2
51	TS-1490041	Hex Cap Bolt	M8x25	2
52	ZX-04109	Screw Support		1
53	ZX-CA53	Oil Cup	8	2
54	ZX-04707-1	Gear Sliding Sleeve	2m16T	1
55	ZX-H10	Half Circle Key	4x16	1
56	ZX-04751	Flat Key		1

Index	Part			
No.	No.	Description	Size	Qty.
57	ZX-04302	Nut Assembly		1
58	ZX-04748	Wedge		1
59	ZX-04707-2	Lead Screw		1
60	BB-51101/P6	Thrust Bearing	12x26x9	2
61	ZX-04116	Bracket		1
62	ZX-CA62	Oil Cup	6	1
63	TS-1491041	Cap Screw	M10x30	2
64	ZX-CA64	Taper Pin	8x30	2
65	ZX-04731	Cross Slide Gib		1
66	ZX-04725C	Screw		2
67	ZX-04102A	Cross Slide		1
68	ZX-04714	Screw (for 18" models, T-Slot)		2
	ZX-04714C	Screw (for 14"/16" models, T-Slot)		2
69	ZX-04732	Pin		1
70	TS-1540081	Hex Nut	M12	2
71	ZX-04709	Sleeve		1
72	ZX-04304	Pressing Pin	1	1
73	ZX-04746	Screw		1
74	ZX-04786	Set Screw		1
75	ZX-CA75	Long Copper Tube		1
76	TS-1504051	Socket Head Cap Screw	M8x22	3
77	ZX-04502	Wipe Plate		1
78	ZX-CA78	Copper Tube		6
79	ZX-04503	Wipe Plate		1
80	ZX-04771	Lining		1
81	ZX-04788	Stop Pin		1
82	ZX-04507	Stop Pin Cap		1
	ZX-CSNA	Crossfeed Screw & Nut Assy. (includes # 57- 59. for 14/16/18")		
	ZX-CDA	Crossfeed Dial Assy. (includes # 41-50, 51-56. for 14/16/18")		


Carriage Stop Assembly



Carriage Stop Assembly

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-26101		Left Support.....		1
2	TS-1504041		Hex Socket Cap Screw	M8x20	4
3	ZX-C34		Taper Pin	6x30	4
4	ZX-26704		Control Ring		1
5	TS-1523031		Set Screw.....	M6x10	2
6	ZX-26702		Eccentric Travel Setting Ring.....		5
7	ZX-H66		Flat End Set Screw	M6x10	10
8	ZX-CS08		Pin	4n6x10	5
9	ZX-26703		Locking Key.....		5
10	ZX-26701A		Travel Setting Rod (for 1440/1640/1840ZX)		1
	ZX-26701B		Travel Setting Rod (for 1460/1660/1860ZX)		1
	ZX-26701C		Travel Setting Rod (for 1880ZX)		1
11	ZX-26705		Control Ring		1
12	ZX-26104		Right Support		1
13	ZX-H5		Steel Ball	8	1
14	ZX-CS14		Compression Spring.....	2x8x25	1
15	ZX-CS15		Flat Head Set Screw	M10x12	1
16	ZX-CS16		Oil Cup	8	2
17	ZX-26301		Dial		1


Four Way Tool Post



Four Way Tool Post

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-04103A		Revolving Plate (for 14" models)		1
	ZX-04103B		Revolving Plate (for 16" models)		1
	ZX-04103C		Revolving Plate (for 18" models)		1
2	ZX-04725		Screw		1
3	ZX-04710		Gib		1
4	ZX-04786		Screw		1
5	ZX-04303		Pressing Block		1
6	ZX-04706		Lead Screw		1
7	ZX-04106A		Nut		1
8	ZX-04107A		Top Slide (for 14" models)		1
	ZX-04107B		Top Slide (for 16"/18" models)		1
9	ZX-04501		Wipe Plate		1
10	ZX-F10		Half Circle Key	3x13	1
11	BB-51102		Thrust Bearing	15x28x9	2
12	ZX-04115		Sleeve		1
13	ZX-F13		Slotted Cheese Head Screw	M5x12	3
14	ZX-F14		Taper Pin	3x18	2
15	ZX-04727		Dial		1
16	ZX-04114		Sleeve		1
17	ZX-04768		Disc Spring		1
18	ZX-04767		Sleeve		1
19	ZX-04726		Handle		1
20	ZX-04771		Lining		1
21	ZX-04763		Spring	0.8x6x25	1
22	ZX-04787		Positioning Block		1
23	ZX-04752A		T-Slot Nut		1
24	ZX-04754		Shaft		1
25	ZX-04759		Adjusting Lining Sheet		1
26	ZX-04110		Lever Support		1
27	ZX-04753		Handle		1
28	ZX-Q66		Taper Pin	5x35	1
29	ZX-04713A		Tool Post (for 14" models)		1
	ZX-04713B		Tool post (for 16"/18" models)		1
30	ZX-F30A		Clamping Screw (for 16"/18" models)	M12x45	8
	ZX-F30B		Clamping Screw (for 14" models)	M12x50	8
31	ZX-F31		Oil Cup	8	1
32	ZX-H211		Countersunk Head Screw	M5x16	3
33	ZX-04725C		Screw		1
34	ZX-F34		Oil Cup	8	2
35	ZX-F35		Spring	0.7x5x9	1
36	ZX-F36		Steel Ball	6	1
37	ZX-F37		Round Nut	M12x1.25	2
38	ZX-CA39		Cross Head Screw	M5x16	1
39	ZX-04746K		Screw Wrench		1
	ZX-TA14		Toolholder Assy.14" (includes # 29 & 30)		
	ZX-TA16/18		Toolholder Assy. 16/18" (includes # 29 & 30)		
	ZX-CPA14		Compound Assy. 14" (includes # 1-20,32-39)		
	ZX-CPA16		Compound Assy. 16" (includes # 1-20,32-39)		
	ZX-CPA18		Compound Assy. 18" (includes # 1-20,32-39)		


Tailstock Assembly I



Tailstock Assembly I

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-03711		Handle.....		1
2	ZX-03717		Lever Support.....		1
3	ZX-03718		Washer.....		1
4	ZX-03719		Clamping Block.....		1
5	ZX-03720		Clamping Block.....		1
6	ZX-T06		Cylindrical End Set Screw.....	M8x14	2
7	ZX-03712		Eccentric Shaft.....		1
10	ZX-03701A		Center Sleeve (for 18" models).....		1
	ZX-03701B		Center Sleeve (for 14"/16" models)		1
11	ZX-T11		Ring Seal.....	75x2.65	1
12	ZX-03703		Front Cover		1
13	ZX-T13		Cross Recessed Countersunk Head Screw	M5x10	4
14	ZX-T14A		Center Morse (for 18" models).....	No.5	1
	ZX-T14B		Center Morse (for 14"/16" models)	No.4	1
22	ZX-03702		Positioning Block.....		1
35	ZX-03714		Eccentric Shaft.....		1
36	ZX-T36		Taper Pin	6x32	1
37	ZX-03104		Lever Sleeve		1
38	ZX-03709		Lock handle.....		1
39	ZX-A28		Taper Pin	6x55	1
40	TS-1504041		Hex Socket Cap Screw	M8x20	4
41	TS-1515031		Hex Socket Cap Screw	M8x22	3
42	ZX-T42		Pin	10n6x22	1
43	ZX-03302		Sign Plate.....		1
45	ZX-T45		Nail	3x8	4
46	ZX-03105		Nut.....		1
47	BB-51205		Thrust Ball Bearing	25x47x15	1
48	ZX-03104		Back Cover.....		1
49	ZX-03103		Hand Wheel		1
50	ZX-03707		Lever		1
51	ZX-T51		Acorn Nut	M16	1
52	TS-2360161		Flat Washer.....	B16	1
53	ZX-T53		Key	6x40	1
54	ZX-03710A		Lead Screw (for 18" models).....		1
	ZX-03710B		Lead Screw (for 14"/16" models)		1
55	ZX-03101A		Tailstock Casting (for 18" models)		1
	ZX-03101B		Tailstock Casting (for 16" models)		1
	ZX-03101C		Tailstock Casting (for 14" models)		1
56	ZX-T56		Oil Cup	8	1
57	ZX-03708		Dial		1
58	ZX-03706		Sleeve		1
59	ZX-03711C		Spring Leaf.....		1
65	TS-2310162		Nut.....	M16	1


Tailstock Assembly II



Tailstock Assembly II

Index	Part		Description	Size	Qty.
No.	No.				
8	ZX-T08		Flat End Set Screw (Except in 14" models)	M6x18	4
9	ZX-T09E		Spring		1
18	ZX-03714		Bearing Support (Except in 14" models)		4
19	ZX-03715		Small Axle (Except in 14" models)		4
20	ZX-T20		Ball Bearing (Except in 14" models)	7x19x6	4
21	ZX-03102A		Sliding Base (for 18" models)		1
	ZX-03102B		Sliding Base (for 16" models)		1
	ZX-03102C		Sliding Base (for 14" models)		1
23	TS-1550071		Flat Washer	M10	2
24	TS-1491151		Hex Cap Bolt (for 18" models)	M10x90	2
	TS-1491121		Hex Cap Bolt (for 16" models)	M10x70	2
	TS-1491081		Hex Cap Bolt (for 14" models)	M10x50	2
25	ZX-03704		Gib		1
26	ZX-03721C		Spherical Washer		2
27	ZX-03718C		Adjusting Screw		2
28	ZX-T28		Taper Washer	16	2
29	ZX-T29		Spherical Washer	16	2
30	TS-2310162		Hex Nut	M16	2
31	ZX-03106		Clamping Bracket		1
32	ZX-03105C		Nut		1
33	ZX-T33		Hex Socket Cap Screw	M8x85	2
34	ZX-03705A		Pulling Rod (for 18" models)		2
	ZX-03705B		Pulling Rod (for 16" models)		2
	ZX-03705C		Pulling Rod (for 14" models)		2
44	ZX-03303		Sign Plate		1
45	ZX-T45		Nail	3x8	4
60	ZX-T60		Half Round Head Screw	M5 x12	10
61	ZX-03721		Plate		1
62	ZX-03502		Wipe Plate		2
63	ZX-03503		Wipe Plate		2
64	ZX-03716		Plate		1
	ZX-TSA14		Tailstock Assy. 14" (includes # 1-13,15-65)		
	ZX-TSA16		Tailstock Assy. 16" (includes # 1-13,15-65)		
	ZX-TSA18		Tailstock Assy. 18" (includes # 1-13,15-65)		


Steady Rest Assembly



Steady Rest Assembly

Index	Part		Description	Size	Qty.
No.	No.				
1	ZX-10702A		Screw (for 14" models).....		3
	ZX-10702B		Screw (for 16" models).....		3
	ZX-10702C		Screw (for 18" models).....		3
2	ZX-10704D		Sliding Sleeve (for 14")	0.78" - 4.33"	3
	ZX-10705D		Sliding Sleeve (for 14")	3.5" - 7"	3
	ZX-10705D		Sliding Sleeve (for 16"/18" models)		3
3	ZX-10301D		Pushing Block (for 14" models).....		3
			Pushing Block (for 16"/18" models)		3
4	ZX-SR04		Slotted Set Screw	M6x20	3
5	ZX-10705		Lever		3
6	ZX-10706		Locking Screw.....		3
7	ZX-C36		Pin	10n6x40	1
8	ZX-10701		Hinge Screw.....		1
9	ZX-SR9		Pin	8n6x40	1
10	ZX-SR10		Hex Nut	M20	1
11	ZX-SR11		Flat Washer.....	20	1
12	ZX-10708		Tightening Screw		1
13	ZX-10103D		Clamping Plate.....		1
14	ZX-10101A		Lower Part of Steady Rest (for 14" models).....		1
	ZX-10101B		Lower Part of Steady Rest (for 16" models).....		1
	ZX-10101C		Lower Part of Steady Rest (for 18" models).....		1
15	ZX-10102AS		Upper Part of Steady Rest (for 14" models).....		1
	ZX-10102BS		Upper Part of Steady Rest (for 16"/18" models)		1
16	ZX-SR16		Round Nut.....	M10	1
	ZX-SRA14		Steady Rest Assy.14" (includes # 1-16)		
	ZX-SRA16		Steady Rest Assy.16" (includes # 1-16)		
	ZX-SRA18		Steady Rest Assy.18" (includes # 1-16)		


Follow Rest Assembly



Follow Rest Assembly

Index	Part		Size	Qty.
No.	No.	Description		
1	ZX-10710	Screw		2
2	ZX-10704	Nut.....		2
3	ZX-10707	Sliding Sleeve		2
4	ZX-10301	Supporting Piece.....		2
5	ZX-FR05	Slotted Set Screw	M6x10	2
6	ZX-10705	Locking Screw.....		2
7	ZX-10706	Handle.....		2
8	ZX-FR08	Hex Cap Bolt.....	M12x55	2
9	ZX-10102A	Follow Rest Casting (for 14" models)		1
	ZX-10102B	Follow Rest Casting (for 16" models)		1
	ZX-10102C	Follow Rest Casting (for 18" models)		1
	ZX-FRA14	Follow Rest Assy.14" (includes # 1-7,9).....		
	ZX-FRA16	Follow Rest Assy.16" (includes # 1-7,9).....		
	ZX-FRA18	Follow Rest Assy.18" (includes # 1-7,9).....		

Coolant & Work Light Assembly




Coolant & Work Light Assembly

Index	Part		Description	Size	Qty.
No.	No.				
1	RT-001A		Rubber Tube (for 1440/1640/1840ZX)	ID 1/2"x1280mm	1
	RT-001B		Rubber Tube (for 1460/1660/1860ZX)	ID 1/2"x1780mm	1
	RT-001C		Rubber Tube (for 1880ZX)	ID 1/2"x2280mm	1
2	ZX-CW02		Hex Cap Bolt	M5x25	4
3	ZX-CW03		Hex Nut	5	4
4	ZX-CW04E		Coolant Pump		1
5	ZX-CW05		Hex Nut	M6	2
6	ZX-01727		Clip For Rubber Tube		2
7	ZX-CW07		Half Round Head Screw	M6x16	2
8	ZX-01728		Fitting		1
9	ZX-01729		Flow Pipe		1
10	ZX-CW10		Coolant Device		1
	ZX-CW10-1		Coolant Tap	G 3/8"	1
11	TS-1514021		Hex Socket Cap Screw	M6x16	2
12	TS-1515051		Hex Socket Cap Screw	M8x40	2
13	ZX-CW13		Lamp Support		1
14	ZX-S04		Cross Head Screw	M6x14	4
15	ZX-CW 15		Lamp Frame		1
	ZX-CW16		Bulb	50W, AC24V	1
	ZX-LA		Light Assy (includes # 13-15)		



Micro Carriage Stop

Index No.	Part No.	Description	Size	Qty.
1	ZX-09709	Dial		1
2	ZX-MS2	Pin	B4x8	1
3	ZX-09708	Axle		1
4	ZX-09105	Stop		1
5	ZX-03302	Sign Plate		1
6	ZX-MS6	Nail	3x8	2
7	ZX-MS7	Hex Socket Set Screw	M6x12	1
8	ZX-09106	Clamping Plate		1
9	ZX-MS9	Hex Socket Cap Screw	M8x20	2




Other Parts

Index	Part		Description	Size	Qty.
No.	No.				
1A	ZX-OP-1A		3-Jaw Chuck (mounted on lathe)	10", D1-8	1
1B	ZX-OP-1B		Chuck Wrench		1
2A	ZX-OP-2A		4-Jaw Chuck	12", D1-8	1
2B	ZX-OP-2B		Chuck Wrench		1
3	ZX-OP-03		12" Face Plate (for 14"/16" models)		1
3	ZX-OP-03N		16" Face Plate (for 18" model only)		1
4	ZX-OP-04		Tool Tightening Wrench		1
5	ZX-OP-05		Cam Tightening Wrench		1
6	ZX-OP-06		Center		1
7	ZX-OP-07		MT-4 Live Center (for 14"/16" models)		1
7	ZX-OP-07N		MT-5 Live Center (for 18" model only)		1
8	ZX-OP-08		Morse Reduction Sleeve		1
9	ZX-OP-09		Oil Gun		1
10	ZX-OP-10		Touch Painting Can		1
11	ZX-OP-11		Gap Bridge Pin Driver		1
12	ZX-OP-12		Hex Wrench	2.5,4,5,6,8,10	1
13	ZX-OP-13		Double End		1
14	ZX-OP-14		Flat Blade Screw Driver		1
15	ZX-OP-15		Cross Point Screw Driver		1
16	ZX-OP-16		Adjustable Wrench		1
17	ZX-OP-17		Round Nut Wrench		1
	ZX-14/16TBCP		Tool Box Complete (not shown)	ZX-14"/16"	
	ZX-18TBCP		Tool Box Complete (not shown)	ZX-18"	




Electric Cabinet


Index No.	Part No.	Description	Size	Qty.
1	ZX-SB1E	Jog Button	LAY12-10	1
2	ZX-SA2E	Coolant Control Button	LAY12-11X/2	1
3	ZX-SB2E	Emergency Stop	LAY12-01ZS/1	1
4	ZX-HLE	Power Indicator Light	LAY12-AD/110V	1
5	SQ2SQ3E	Stroke Switch	LWX5-11D1	2
6	ZX-QF	Master Switch (40A)	D215-40	1
7	ZX-FU1	Fuse (3A)	JRT1-16A	1
8	ZX-FU2	Fuse (2A)	JRT1-16A	1
9	ZX-FU3	Fuse (2A)	JRT1-16A	1
10	ZX-FU5	Fuse (2A)	JRT1-16A	1
	ZX-FB	Fuse Block		1
11	ZX-QE	Temperature Relay	JW6	1
12	ZX-KM2E	A.C. Contactor	3TB40	1
13	ZX-KAE	A.C. Contactor	3TB80	1
14	ZX-KM3E	A.C. Contactor	3TB43	1
15	ZX-KM4E	A.C. Contactor	3TB43	1
16	ZX-XBE	Copper Plate (for grounding)		1
17	ZX-XT1E	Wiring Board	JT1	1
18	ZX-XT2E	Wiring Board	JX0	1
19	ZX-TCE	Control Transformer	JBK3-100-TH	1
20	ZX-SQ1E	Stroke Switch	LWX5-11N1	1
21	SQ4E	Stroke Switch	LWX5-11Q1	1



Wiring Diagram




Protecting guards for three rods



Index No.	Part No.	Description	Size	Qty.
1	ZX-20701E	Splash Guard		1
2	ZX-20702E	Splash Guard		1
3	ZX-P03E	Hex Socket Cap Screw	M5x8	4
4	ZX-11304E	Thread Chasing Label.....		1
5	ZX-P05E	Half Round Head Screw	M3x6	6

Safety guard cover



Index No.	Part No.	Description	Size	Qty.
1	ZX-19701AE	Protection guard.....		1
2	ZX-19501E	Protection guard visual glass.....		1
3	ZX-19704E	Fixing rod		1
4	ZX-S04E	Handle.....	Z96-6.....	1
5	ZX-S05E	Plain washers.....	6.....	2
6	ZX-S06E	Cross recessed pan head screws.....	M6x12.....	2
7	ZX-S07E	Hexagon thin nuts	M4.....	6
8	ZX-S08E	Plain washers.....	4.....	6
9	ZX-S09E	Cross recessed pan head screws.....	M4x12.....	6
10	ZX-S10E	Plain washers.....	5.....	4
11	ZX-S11E	Hexagon socket cap head screws	M5x16.....	4
12	ZX-19703AE	Rest bar.....		1
13	ZX-S13E	Slotted set screws.....	M5x10.....	2
14	ZX-S14E	Hexagon socket cap head screws	M6x35.....	4
15	ZX-S15E	Hexagon socket set screws	M8x16.....	1
16	GH1440A-19101AE	Switch box.....		1
17	ZX-S17E	Stroke switch.....	LWX5-11Q1	1
18	ZX-S18E	Slotted pan head screws.....	M4x25	2
19	ZX-19702AE	Shaft.....		1