

JET


MBS-2128DAS**MITER METALWORKING
BANDSAW****MBS-2128DAS..... 3~400V, 50Hz**

PARTS LIST

JPW (Tool) AG.
Tämperlistrasse 5
CH-8117 Fällanden
Switzerland
Phone +41 44 806 47 48
Fax +41 44 806 47 58
www.jettools.com

50000343T**2014-02**

MBS-2128DAS Stand Assembly



MBS-2128DAS Stand Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|----------------------|----------------------------------|---------------------|------------|
| 1 | MBS2128DAS-A1 | Hex. socket cap screw | 3/8"x1" L | 1 |
| 2 | MBS2128DAS-A2 | Spring Washer | 3/8" | 1 |
| 3 | MBS2128DAS-A3 | Washer | | 1 |
| 4 | MBS2128DAS-A4 | Set screw | 5/16"x5/16" L | 1 |
| 5 | MBS2128DAS-A5 | Holding bracke | | 1 |
| 6 | MBS2128DAS-A6 | Hex. socket cap screw | 3/8"x1" L | 1 |
| 7 | MBS2128DAS-A7 | Spring washer | 3/8" | 1 |
| 8 | MBS2128DAS-A8 | Washer | | 1 |
| 9 | MBS2128DAS-A9 | Spring washer | 3/8" | 1 |
| 10 | MBS2128DAS-A10 | Hex. socket cap screw | 3/8"x1" L | 1 |
| 11 | MBS2128DAS-A11 | Length bar bracket | | 1 |
| 12 | MBS2128DAS-A12 | Stopper | | 1 |
| 13 | MBS2128DAS-A13 | Welding shaft | | 1 |
| 14 | MBS2128DAS-A14 | Length bar | | 1 |
| 15 | MBS2128DAS-A15 | Adjusting block | | 1 |
| 16 | MBS2128DAS-A16 | Locking handle | 3/8x30L | 1 |
| 17 | MBS2128DAS-A17 | Washer | | 1 |
| 18 | MBS2128DAS-A18 | Spring washer | 3/8" | 1 |
| 19 | MBS2128DAS-A19 | Hex. socket cap screw | 3/8"x1" L | 1 |
| 20 | MBS2128DAS-A20 | Length bar bracket (R) | | 1 |
| 21 | MBS2128DAS-A21 | Set screw | 5/16"x5/16" L | 1 |
| 22 | MBS2128DAS-A22 | Washer | | 1 |
| 23 | MBS2128DAS-A23 | Spring washer | 3/8" | 1 |
| 24 | MBS2128DAS-A24 | Hex. socket cap screw | 3/8"x1" L | 1 |
| 25 | MBS2128DAS-A25 | Hex. cap bolt | M10x25L | 4 |
| 26 | MBS2128DAS-A26 | Spring washer | M10 | 4 |
| 27 | MBS2128DAS-A27 | Flat washer | M10 | 4 |
| 28 | MBS2128DAS-A28 | Flat head screw | 5/16"x3/4" L | 4 |
| 29 | MBS2128DAS-A29 | Side plate | | 1 |
| 30 | MBS2128DAS-A30 | Coolant tray bracket | | 2 |
| 31 | MBS2128DAS-A31 | Machine base | | 1 |
| 32 | MBS2128DAS-A32 | Movable cover | | 1 |
| 33 | MBS2128DAS-A33 | U Type handle | | 1 |
| 34 | MBS2128DAS-A34 | Big round head screw | M6x12L | 2 |
| 35 | MBS2128DAS-A35 | Flat washer | M12 | 4 |
| 36 | MBS2128DAS-A36 | Spring washer | M12 | 4 |
| 37 | MBS2128DAS-A37 | Hex. cap bolt | M12x25L | 4 |
| 38 | MBS2128DAS-A38 | Retrieving device | | 1 |
| 39 | MBS2128DAS-A39 | Coolant tray (R) | | 1 |
| 40 | MBS2128DAS-A40 | Round head socket screw | M6x8L | 4 |
| 41 | MBS2128DAS-A41 | Inverter cover | | 1 |
| 42 | MBS2128DAS-A42 | Coolant tray bracket (R/L) | | 3 |
| 43 | MBS2128DAS-A43 | Inverter | 7.5HP | 1 |
| 44 | MBS2128DAS-A44 | Round head screw | M5x12L | 4 |
| 45 | MBS2128DAS-A45 | Hydraulic unit | | 1 |
| 46 | MBS2128DAS-A46 | Round head socket screw | M6x12L | 2 |
| 47 | MBS2128DAS-A47 | Hydraulic unit cover | | 1 |
| 48 | MBS2128DAS-A48 | Round head socket screw | M6x8L | 4 |
| 49 | MBS2128DAS-A49 | Coolant tray bracket (RF) | | 1 |
| 50 | MBS2128DAS-A50 | Steel hex. cap bolt | M16x60L | 4 |
| 51 | MBS2128DAS-A51 | Nut | M16 | 4 |
| 52 | MBS2128DAS-A52 | Pressure regulator | | 1 |
| 52-1 | MBS2128DAS-A52-1.. | Movable coolant tray | | 2 |
| 52-2 | MBS2128DAS-A52-2.. | Hex. cap bolt | M6x12L | 4 |
| 52-3 | MBS2128DAS-A52-3.. | Tray bracket | | 2 |
| 52-4 | MBS2128DAS-A52-4.. | Nut | M6 | 4 |
| 52-5 | MBS2128DAS-A52-5.. | Nut | 1/2" | 2 |
| 52-6 | MBS2128DAS-A52-6.. | Adjusting screw | | 2 |
| 53 | MBS2128DAS-A53 | Lock pin | 8x50L | 2 |
| 54 | MBS2128DAS-A54 | Hex. socket cap screw | M6x30L | 1 |
| 55 | MBS2128DAS-A55 | Spring washer | M6 | 1 |


MBS-2128DAS Stand Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|--------------------|-------------------------------|----------------|------------|
| 56 | MBS2128DAS-A56 | Flat washer | M6..... | 1 |
| 57 | MBS2128DAS-A57 | Cabinet door | | 1 |
| 58 | MBS2128DAS-A58 | Round head socket screw | M6x16L..... | 4 |
| 59 | MBS2128DAS-A59 | Control base | | 1 |
| 60 | MBS2128DAS-A60 | Round head socket screw | M6x16L..... | 4 |
| 61 | MBS2128DAS-A61 | Spring washer | M6..... | 4 |
| 62 | MBS2128DAS-A62 | Electrical box | | 1 |
| 63 | MBS2128DAS-A63 | Flat washer | M10..... | 4 |
| 64 | MBS2128DAS-A64 | Spring washer | M10..... | 4 |
| 65 | MBS2128DAS-A65 | Hex. cap bolt | M10x30L..... | 4 |
| 66 | MBS2128DAS-A66 | Spring washer | M10..... | 4 |
| 67 | MBS2128DAS-A67 | Hex. cap bolt | M10x30L..... | 4 |
| 68-1 | MBS2128DAS-A68-1.. | Moving shaft | | 1 |
| 69 | MBS2128DAS-A69 | Shaft holder base | | 2 |
| 70 | MBS2128DAS-A70 | Shaft holder | | 2 |
| 71 | MBS2128DAS-A71 | Back cover | | 1 |
| 72 | MBS2128DAS-A72 | Round head screw | M5x12L..... | 4 |
| 73 | MBS2128DAS-A73 | Nut | M8..... | 10 |
| 74 | MBS2128DAS-A74 | Spring washer | M8..... | 10 |
| 75 | MBS2128DAS-A75 | Flat washer | M8..... | 10 |
| 76 | MBS2128DAS-A76 | Coolant tray (L) | | 1 |
| 77 | MBS2128DAS-A77 | Hex. cap bolt | M8x20L..... | 10 |
| 78 | MBS2128DAS-A78 | Flat head screw | M12x30L..... | 5 |
| 79 | MBS2128DAS-A79 | Swiveling guide plate | | 1 |
| 80 | MBS2128DAS-A80 | Hex. cap bolt | M6x16L..... | 2 |
| 81 | MBS2128DAS-A81 | Spring washer | M6..... | 2 |
| 82 | MBS2128DAS-A82 | Coolant pump | 1/6"x150L..... | 1 |
| 83 | MBS2128DAS-A83 | Coolant pump bracket | | 1 |
| 84 | MBS2128DAS-A84 | Round head socket screw | M6x8L..... | 2 |
| 85 | MBS2128DAS-A85 | Pump cover | | 1 |
| 86 | MBS2128DAS-A86 | Round head socket screw | M6x8L..... | 4 |
| 87 | MBS2128DAS-A87 | Chip collected | | 1 |
| 88 | MBS2128DAS-A88 | Coolant tray (B) | | 1 |
| 89 | MBS2128DAS-A89 | Flat washer | M8..... | 2 |
| 90 | MBS2128DAS-A90 | Spring washer | M8..... | 2 |
| 91 | MBS2128DAS-A91 | Hex. cap bolt | M8x16L..... | 2 |
| 92 | MBS2128DAS-A92 | Round head socket screw | M6x8L..... | 6 |
| 93 | MBS2128DAS-A93 | Round head socket screw | M6x8L..... | 4 |
| 94 | MBS2128DAS-A94 | Cover | | 1 |
| 95 | MBS2128DAS-A95 | Round head socket screw | M6x8L..... | 4 |
| 96 | MBS2128DAS-A96 | Control box | | 1 |
| 97 | MBS2128DAS-A97 | U type handle | | 2 |
| 98 | MBS2128DAS-A98 | Control PCB | | 1 |
| 99 | MBS2128DAS-A99 | Round head socket screw | M5x8L..... | 4 |
| 100 | MBS2128DAS-A100... | Bow height PCB | | 1 |
| 101 | MBS2128DAS-A101... | Round head socket screw | M4x6L..... | 2 |
| 102 | MBS2128DAS-A102... | Magnifier | | 1 |
| 103 | MBS2128DAS-A103... | Magnifier holder | | 1 |
| 104 | MBS2128DAS-A104... | Height scale cover | | 1 |
| 105 | MBS2128DAS-A105... | Round head socket screw | M4x6L..... | 2 |
| 106 | MBS2128DAS-A106... | Nut | M6..... | 2 |
| 107 | MBS2128DAS-A107... | Cover bracket | | 1 |
| 108 | MBS2128DAS-A108... | Round head socket screw | M4x12L..... | 2 |
| 109 | MBS2128DAS-A109... | Bracket cover | | 1 |
| 110 | MBS2128DAS-A110... | Round head screw | M6x8L..... | 6 |
| 111 | MBS2128DAS-A111... | Control box bracket | | 1 |
| 112 | MBS2128DAS-A112... | Round head socket screw | M6x8L..... | 4 |
| 113 | MBS2128DAS-A113... | Swiveling bracket | | 1 |
| 114 | MBS2128DAS-A114... | Hex. cap bolt | M6x16L..... | 4 |
| 115 | MBS2128DAS-A115... | Hex. cap bolt | M8x16L..... | 4 |
| 116 | MBS2128DAS-A116... | Spring washer | M8..... | 4 |

MBS-2128DAS Stand Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|--------------------|-----------------------|-------------|------------|
| 117 | MBS2128DAS-A117... | Swiveling base | | 1 |
| 118 | MBS2128DAS-A118... | Adjusting handle..... | M8x30L..... | 1 |
| 119 | MBS2128DAS-A119... | Set screw..... | M8x20L..... | 2 |
| 120 | MBS2128DAS-A120... | Nut..... | M8..... | 2 |
| 121 | MBS2128DAS-A121... | Spring washer | M8..... | 4 |
| 122 | MBS2128DAS-A122... | Hex. cap bolt | M8x16L..... | 4 |
| 123 | MBS2128DAS-A123... | Connect base | | 1 |

MBS-2128DAS Rotary Mechanism Assembly



MBS-2128DAS Rotary Mechanism Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|----------------------|-------------------------------|--------------|------------|
| 1 | MBS2128DAS-B1 | Round head socket screw | M5x8L..... | 4 |
| 2 | MBS2128DAS-B2 | Dust Cover | | 1 |
| 3 | MBS2128DAS-B3 | Rubber handle | | 1 |
| 4 | MBS2128DAS-B4 | Nut | M12..... | 1 |
| 5 | MBS2128DAS-B5 | Locking rod | | 1 |
| 6 | MBS2128DAS-B6 | Locking bolt | | 1 |
| 7 | MBS2128DAS-B7 | Connecting block | | 1 |
| 8 | MBS2128DAS-B8 | Hex. socket cap screw | M10x50L..... | 1 |
| 9 | MBS2128DAS-B9 | Brake plate | | 1 |
| 10 | MBS2128DAS-B10 | Hex. socket cap screw | M8x20L..... | 2 |
| 11 | MBS2128DAS-B11 | Brake bracket | | 1 |
| 12 | MBS2128DAS-B12 | Hex. socket cap screw | M10x40L..... | 1 |
| 13 | MBS2128DAS-B13 | Cam spring | | 1 |
| 14 | MBS2128DAS-B14 | Nut | M10..... | 1 |
| 15 | MBS2128DAS-B15 | Connecting plate | | 1 |
| 16 | MBS2128DAS-B16 | C Ring | S16 | 1 |
| 17 | MBS2128DAS-B17 | Hex. socket cap screw | M8x25L..... | 1 |
| 18 | MBS2128DAS-B18 | Cam bracket | | 1 |
| 19 | MBS2128DAS-B19 | Cam shaft | | 1 |
| 20 | MBS2128DAS-B20 | Bearing | 6000ZZ | 1 |
| 21 | MBS2128DAS-B21 | Spring washer | M10..... | 1 |
| 22 | MBS2128DAS-B22 | Nut | M10..... | 1 |
| 23 | MBS2128DAS-B23 | Spring pin | 8x20L..... | 2 |
| 24 | MBS2128DAS-B24 | Hex. socket cap screw | M10x20L..... | 5 |
| 25 | MBS2128DAS-B25 | Spring washer | M10..... | 5 |
| 26 | MBS2128DAS-B26 | Hex. socket cap screw | M10x20L..... | 8 |
| 27 | MBS2128DAS-B27 | Steel hex. cap bolt | M5x15L..... | 1 |
| 28 | MBS2128DAS-B28 | Wire fastener | | 1 |
| 29 | MBS2128DAS-B29 | Angle position plate | | 1 |
| 30 | MBS2128DAS-B30 | Lower Cover | | 1 |
| 31 | MBS2128DAS-B31 | O Ring | P60 | 2 |
| 32 | MBS2128DAS-B32 | Taper bearing | 30312 | 2 |
| 33 | MBS2128DAS-B33 | Swiveling | | 1 |
| 34 | MBS2128DAS-B34 | Swiveling shaft | | 1 |
| 35 | MBS2128DAS-B35 | Upper cover | | 1 |
| 36 | MBS2128DAS-B36 | Set screw | M6x25L..... | 1 |
| 37 | MBS2128DAS-B37 | Hex. socket cap screw | M8x20L..... | 8 |
| 38 | MBS2128DAS-B38 | Tighten plate | | 1 |
| 39 | MBS2128DAS-B39 | Hex. socket cap screw | M8x20L..... | 2 |
| 40 | MBS2128DAS-B40 | Cylinder lower bracket | | 1 |
| 41 | MBS2128DAS-B41 | Hex. cap bolt | M10x60L..... | 1 |
| 42 | MBS2128DAS-B42 | Hex. cap bolt | M20x65L..... | 1 |
| 43 | MBS2128DAS-B43 | Nut | M10..... | 1 |
| 44 | MBS2128DAS-B44 | Nut | M20..... | 1 |
| 45 | MBS2128DAS-B45 | Dust cover | | 1 |
| 46 | MBS2128DAS-B46 | Fixing plate | | 1 |
| 47 | MBS2128DAS-B47 | Spring washer | M6..... | 3 |
| 48 | MBS2128DAS-B48 | Round head socket screw | M6x20L..... | 3 |
| 49 | MBS2128DAS-B49 | Support bracket | | 2 |
| 50 | MBS2128DAS-B50 | Bearing | 6201 | 2 |
| 51 | MBS2128DAS-B51 | Bearing shaft | | 2 |
| 52 | MBS2128DAS-B52 | Set screw | M4x6L..... | 2 |
| 53 | MBS2128DAS-B53 | Hex. socket cap screw | M8x20L..... | 4 |
| 54 | MBS2128DAS-B54 | Spring washer | M8..... | 4 |
| 55 | MBS2128DAS-B55 | Steel hex. cap bolt | M8x40L..... | 4 |
| 56 | MBS2128DAS-B56 | Spring washer | M8..... | 4 |
| 57 | MBS2128DAS-B57 | Adjusting screw | M16 | 4 |
| 58 | MBS2128DAS-B58 | Support plate | | 1 |
| 59 | MBS2128DAS-B59 | Nut | 1/2" | 2 |


MBS-1824DAS Rotary Mechanism Assembly

| Index No. | Part No. | Description | Size | Qty |
|-----------|------------------|------------------------------|---------------|-----|
| 60 | MBS2128DAS-B60 | Spring washer | 1/2" | 2 |
| 61 | MBS2128DAS-B61 | Hex. socket cap screw | M8x25L | 4 |
| 62 | MBS2128DAS-B62 | Spring washer | M8..... | 4 |
| 63 | MBS2128DAS-B63 | Set plate | | 1 |
| 64 | MBS2128DAS-B64 | Screw holder | 1/2"x50L | 2 |
| 65 | MBS2128DAS-B65 | Coolant nozzle..... | 1/4"x30" | 1 |
| 66 | MBS2128DAS-B66 | Wing screw..... | M6x20L..... | 2 |
| 67 | MBS2128DAS-B67 | Nozzle seat..... | | 1 |
| 68 | MBS2128DAS-B68 | Coolant switch | 1/4x1/4..... | 1 |
| 69 | MBS2128DAS-B69 | Hex. socket cap screw | M12x30L..... | 12 |
| 70 | MBS2128DAS-B70 | Vise jaw-Right | | 1 |
| 71 | MBS2128DAS-B71 | Vise Jaw-Left..... | | 1 |
| 72 | MBS2128DAS-B72 | Hex. socket cap screw | M8x20L..... | 2 |
| 73 | MBS2128DAS-B73 | Hex. socket cap screw | M8x90L..... | 2 |
| 74 | MBS2128DAS-B74 | Cutting plate | | 1 |
| 75 | MBS2128DAS-B75 | Hex. socket cap screw | M10x90L..... | 2 |
| 75-1 | MBS2128DAS-B75-1 | Pin | | 2 |
| 76 | MBS2128DAS-B76 | Bed plate | | 1 |
| 77 | MBS2128DAS-B77 | Hex. socket cap screw | M10x35L..... | 4 |
| 78 | MBS2128DAS-B78 | Shaft locking block | | 2 |
| 79 | MBS2128DAS-B79 | Spring pin | 8x20L..... | 2 |
| 80 | MBS2128DAS-B80 | Bed | | 1 |
| 81 | MBS2128DAS-B81 | Round head socket screw..... | M6x8L..... | 4 |
| 82 | MBS2128DAS-B82 | Left cover..... | | 1 |
| 83 | MBS2128DAS-B83 | Round head socket screw..... | M6x8L..... | 2 |
| 84 | MBS2128DAS-B84 | Round head socket screw..... | M4x6L..... | 2 |
| 85 | MBS2128DAS-B85 | Magnifier holder..... | | 1 |
| 86 | MBS2128DAS-B86 | Magnifier..... | | 1 |
| 87 | MBS2128DAS-B87 | Wheel cover | | 1 |
| 88 | MBS2128DAS-B88 | Hex. socket cap screw | M10x40L..... | 1 |
| 89 | MBS2128DAS-B89 | Flat washer | M10..... | 1 |
| 90 | MBS2128DAS-B90 | Angle Wheel | | 1 |
| 91 | MBS2128DAS-B91 | Wire fastener | | 1 |
| 92 | MBS2128DAS-B92 | Steel hex. cap bolt..... | M5x15L..... | 1 |
| 93 | MBS2128DAS-B93 | Shaft bush | | 1 |
| 94 | MBS2128DAS-B94 | Steel wire..... | | 1 |
| 95 | MBS2128DAS-B95 | Angle spring | | 1 |
| 96 | MBS2128DAS-B96 | Guide shaft | | 1 |
| 97 | MBS2128DAS-B97 | Hex. socket cap screw | M12x35L..... | 6 |
| 98 | MBS2128DAS-B98 | Set screw..... | M12x25L..... | 4 |
| 99 | MBS2128DAS-B99 | Hex. socket cap screw | M10x30L..... | 4 |
| 100 | MBS2128DAS-B100 | Spring washer | M10..... | 4 |
| 101 | MBS2128DAS-B101 | Vise cylinder | | 1 |
| 102 | MBS2128DAS-B102 | Oilless bush | 5540..... | 2 |
| 113 | MBS2128DAS-B113 | Steel hex. cap bolt..... | M12x45L..... | 6 |
| 114 | MBS2128DAS-B114 | Spring washer | M12..... | 6 |
| 115 | MBS2128DAS-B115 | Cylinder bracket | | 1 |
| 116 | MBS2128DAS-B116 | Spring pin | 8x30L..... | 1 |
| 117 | MBS2128DAS-B117 | Connecting plate | | 1 |
| 118 | MBS2128DAS-B118 | Adjusting screw | M16..... | 4 |
| 119 | MBS2128DAS-B119 | Spring washer | M8..... | 4 |
| 120 | MBS2128DAS-B120 | Steel hex. cap bolt..... | M8x40L..... | 4 |
| 121 | MBS2128DAS-B121 | Hex. socket cap screw | M10x80L..... | 4 |
| 122 | MBS2128DAS-B122 | Linear bearing base..... | SMA40UU | 1 |
| 134 | MBS2128DAS-B134 | Vise base | | 1 |
| 135 | MBS2128DAS-B135 | Guide plate | | 1 |
| 136 | MBS2128DAS-B136 | Hex. socket cap screw | M12x35L..... | 4 |
| 137 | MBS2128DAS-B137 | Hex. cap bolt | M8x20L..... | 4 |
| 138 | MBS2128DAS-B138 | Spring washer | M8..... | 4 |

MBS-2128DAS Rotary Mechanism Assembly

| Index No.. Part No. | Description | Size | Qty |
|----------------------------|--|-------------|------------|
| 139 | MBS2128DAS-B139... Table plate..... | | 1 |
| 140 | MBS2128DAS-B140... Front vise slider | | 1 |
| 141 | MBS2128DAS-B141... Hex. socket cap screw | M12x30L | 2 |
| 142 | MBS2128DAS-B142... Movable vise | | 1 |
| 143 | MBS2128DAS-B143... Flat head screw | M12x30L | 2 |
| 144 | MBS2128DAS-B144... Attached plate | | 1 |
| 145 | MBS2128DAS-B145... Hex. socket cap screw | M8x20L | 4 |
| 146 | MBS2128DAS-B146... Handle | M12x45L | 1 |
| 147 | MBS2128DAS-B147... Tighten copper | | 1 |
| 148 | MBS2128DAS-B148 .. Steel hex. cap bolt..... | M12x30L | 2 |
| 149 | MBS2128DAS-B149 .. Spring washer | M12 | 2 |
| 150 | MBS2128DAS-B150 .. Flat washer | M12 | 2 |
| 151 | MBS2128DAS-B151 .. Vise locking block..... | | 1 |
| 152 | MBS2128DAS-B152... Adjusting screw | | 2 |
| 153 | MBS2128DAS-B153... Nut | M12 | 2 |
| 154 | MBS2128DAS-B154... Locking bracket | | 2 |
| 155 | MBS2128DAS-B155... Spring washer | M8 | 4 |
| 156 | MBS2128DAS-B156... Hex. socket cap screw | M10x80L | 4 |
| 157 | MBS2128DAS-B157... Hex. socket cap screw | M5x12L | 2 |
| 158 | MBS2128DAS-B158... Nut | M5 | 2 |
| 159 | MBS2128DAS-B159... Vise locking plate | | 1 |
| 160 | MBS2128DAS-B160... Lining copper..... | | 1 |
| 161 | MBS2128DAS-B161... Flat head screw | M5x12L | 2 |

MBS-2128DAS Bow Assembly



MBS-2128DAS Bow Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|-----------------|-------------------------------|----------------|------------|
| 1 | MBS-2128DAS-C1 | Round head socket screw..... | M8x25L..... | 4 |
| 2 | MBS-2128DAS-C2 | Safe locker | | 1 |
| 3 | MBS-2128DAS-C3 | Spring..... | | 1 |
| 4 | MBS-2128DAS-C4 | Set screw | M4x12L..... | 2 |
| 5 | MBS-2128DAS-C5 | Bush | | 1 |
| 6 | MBS-2128DAS-C6 | Hex. cap bolt | M8x20L..... | 2 |
| 7 | MBS-2128DAS-C7 | Spring washer | M8..... | 2 |
| 8 | MBS-2128DAS-C8 | Hex. cap bolt | M8x20L..... | 1 |
| 9 | MBS-2128DAS-C9 | Holding bracket | | 1 |
| 10 | MBS-2128DAS-C10 | Bush | | 1 |
| 11 | MBS-2128DAS-C11 | Long bracket | | 1 |
| 12 | MBS-2128DAS-C12 | Short bracket | | 1 |
| 13 | MBS-2128DAS-C13 | Nut | M8..... | 2 |
| 14 | MBS-2128DAS-C14 | Bush | | 1 |
| 15 | MBS-2128DAS-C15 | Hex. socket cap screw | M12x155L..... | 4 |
| 16 | MBS-2128DAS-C16 | Spring washer | M12..... | 4 |
| 17 | MBS-2128DAS-C17 | Hex. socket cap screw | M4x30L..... | 2 |
| 18 | MBS-2128DAS-C18 | Safety limit switch | AZD-S11..... | 1 |
| 19 | MBS-2128DAS-C19 | Blade tension cylinder | | 1 |
| 20 | MBS-2128DAS-C20 | Tension slider | | 1 |
| 21 | MBS-2128DAS-C21 | Limit switch | AZD-1001T..... | 1 |
| 22 | MBS-2128DAS-C22 | Hex. socket cap screw | M4x30L..... | 2 |
| 23 | MBS-2128DAS-C23 | Slide plate | | 2 |
| 24 | MBS-2128DAS-C24 | Idle wheel washer | | 1 |
| 25 | MBS-2128DAS-C25 | Spring washer | M12..... | 1 |
| 26 | MBS-2128DAS-C26 | Steel hex. cap bolt | M12x30L..... | 1 |
| 27 | MBS-2128DAS-C27 | Hex. socket cap screw | M8x25L..... | 6 |
| 28 | MBS-2128DAS-C28 | Spring washer | M8..... | 6 |
| 29 | MBS-2128DAS-C29 | Steel hex. cap bolt | M14x55L..... | 3 |
| 30 | MBS-2128DAS-C30 | Spring washer | M14..... | 3 |
| 31 | MBS-2128DAS-C31 | Adjusting screw | | 3 |
| 32 | MBS-2128DAS-C32 | Slider seat | | 1 |
| 33 | MBS-2128DAS-C33 | Idle wheel shaft | | 1 |
| 34 | MBS-2128DAS-C34 | Hex. socket cap screw | M4x30L..... | 2 |
| 35 | MBS-2128DAS-C35 | Limit switch | AZD-1001T..... | 1 |
| 36 | MBS-2128DAS-C36 | Oilless bush | 4040..... | 1 |
| 37 | MBS-2128DAS-C37 | Hex. cap bolt | M10x20L..... | 1 |
| 38 | MBS-2128DAS-C38 | Flat washer | M10..... | 1 |
| 39 | MBS-2128DAS-C39 | Spring washer | M10..... | 1 |
| 40 | MBS-2128DAS-C40 | Nut | M10..... | 1 |
| 41 | MBS-2128DAS-C41 | Sensor bracket | | 1 |
| 42 | MBS-2128DAS-C42 | VR sensor | | 1 |
| 43 | MBS-2128DAS-C43 | Round head socket screw | M4x10L..... | 2 |
| 44 | MBS-2128DAS-C44 | Sensor cover | | 1 |
| 45 | MBS-2128DAS-C45 | Round head socket screw | M5x8L..... | 4 |
| 46 | MBS-2128DAS-C46 | Key | 20x12x50L..... | 1 |
| 47 | MBS-2128DAS-C47 | Worm reducer | 135#..... | 1 |
| 48 | MBS-2128DAS-C48 | C Ring | S-20..... | 2 |
| 49 | MBS-2128DAS-C49 | Bracket shaft | | 1 |
| 50 | MBS-2128DAS-C50 | Adjusting screw | | 1 |
| 51 | MBS-2128DAS-C51 | Key | 4x4x10L..... | 1 |
| 52 | MBS-2128DAS-C52 | Adjusting handle | | 1 |
| 53 | MBS-2128DAS-C53 | Flat washer | M6..... | 1 |
| 54 | MBS-2128DAS-C54 | Hex. socket cap screw | M6x12L..... | 1 |
| 55 | MBS-2128DAS-C55 | Hex. cap bolt | M10x30L..... | 4 |
| 56 | MBS-2128DAS-C56 | Spring washer | M10..... | 4 |
| 57 | MBS-2128DAS-C57 | Flat washer | M10..... | 4 |
| 58 | MBS-2128DAS-C58 | Motor | 7.5HP | 1 |
| 59 | MBS-2128DAS-C59 | Key | 10x8x70L..... | 1 |

MBS-2128DAS Bow Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|-------------------|-------------------------|-------------|------------|
| 60 | MBS-2128DAS-C60 | Adjusting bracket | | 1 |
| 61 | MBS-2128DAS-C61 | Hex. socket cap screw | M8x20L | 4 |
| 62 | MBS-2128DAS-C62 | Spring washer | M8 | 4 |
| 63 | MBS-2128DAS-C63 | Shaft holder | | 1 |
| 64 | MBS-2128DAS-C64 | Spring pin | 8x20L | 2 |
| 65 | MBS-2128DAS-C65 | Key | 12x8x70L | 1 |
| 65-1 | MBS-2128DAS-C65-1 | Round head socket screw | M6x8L | 4 |
| 65-2 | MBS-2128DAS-C65-2 | Cable fitting | | 1 |
| 66 | MBS-2128DAS-C66 | Saw head | | 1 |
| 67 | MBS-2128DAS-C67 | Round head socket screw | M5x8L | 1 |
| 68 | MBS-2128DAS-C68 | Belt cover | | 1 |
| 69 | MBS-2128DAS-C69 | Round head socket screw | M5x8L | 3 |
| 70 | MBS-2128DAS-C70 | Belt | 22-670C | 2 |
| 71 | MBS-2128DAS-C71 | Set screw | M8x8L | 1 |
| 72 | MBS-2128DAS-C72 | Motor pulley | | 1 |
| 73 | MBS-2128DAS-C73 | Reducer pulley | | 1 |
| 74 | MBS-2128DAS-C74 | Locking washer | | 1 |
| 75 | MBS-2128DAS-C75 | Spring washer | | 1 |
| 76 | MBS-2128DAS-C76 | Steel hex. cap bolt | | 1 |
| 77 | MBS-2128DAS-C77 | Cover plate | | 1 |
| 78 | MBS-2128DAS-C78 | Round head socket screw | M5x8L | 4 |
| 79 | MBS-2128DAS-C79 | Wheel cover plate | | 1 |
| 80 | MBS-2128DAS-C80 | Round head socket screw | M5x8L | 6 |
| 81 | MBS-2128DAS-C81 | Hex. socket cap screw | M6x16L | 3 |
| 82 | MBS-2128DAS-C82 | Wheel shaft cover | | 1 |
| 83 | MBS-2128DAS-C83 | Bearing nut | AN14 | 1 |
| 84 | MBS-2128DAS-C84 | Teeth washer | AW14 | 1 |
| 85 | MBS-2128DAS-C85 | Idle wheel | | 1 |
| 86 | MBS-2128DAS-C86 | Taper bearing | 32014 | 2 |
| 87 | MBS-2128DAS-C87 | Hex. socket cap screw | M10x30L | 4 |
| 88 | MBS-2128DAS-C88 | Spring washer | M10 | 4 |
| 89 | MBS-2128DAS-C89 | Flat washer | M10 | 4 |
| 90 | MBS-2128DAS-C90 | Support plate | | 2 |
| 91 | MBS-2128DAS-C91 | Press block | | 1 |
| 92 | MBS-2128DAS-C92 | Spring washer | M8 | 2 |
| 93 | MBS-2128DAS-C93 | Hex. socket cap screw | M8x40L | 2 |
| 94 | MBS-2128DAS-C94 | Guide roller shaft | | 2 |
| 95 | MBS-2128DAS-C95 | Guide roller | | 2 |
| 96 | MBS-2128DAS-C96 | Bearing | 6005 | 4 |
| 97 | MBS-2128DAS-C97 | C Ring | R47 | 2 |
| 98 | MBS-2128DAS-C98 | Flat washer | M12 | 2 |
| 99 | MBS-2128DAS-C99 | Hex. socket cap screw | M12x60L | 2 |
| 100 | MBS-2128DAS-C100 | Spring washer | M12 | 2 |
| 101 | MBS-2128DAS-C101 | C Ring | S20 | 4 |
| 102 | MBS-2128DAS-C102 | Lower shaft | | 1 |
| 103 | MBS-2128DAS-C103 | Lower bracket | | 1 |
| 104 | MBS-2128DAS-C104 | Hex. socket cap screw | M8x20L | 2 |
| 105 | MBS-2128DAS-C105 | Lift cylinder | | 1 |
| 106 | MBS-2128DAS-C106 | Nut | M20xP1.5 | 1 |
| 107 | MBS-2128DAS-C107 | Eye bearing | POS20 | 1 |
| 108 | MBS-2128DAS-C108 | Upper shaft | | 1 |
| 109 | MBS-2128DAS-C109 | Saw head shaft | | 1 |
| 110 | MBS-2128DAS-C110 | Shaft washer | | 1 |
| 111 | MBS-2128DAS-C111 | Oilless bush | 4040 | 1 |
| 112 | MBS-2128DAS-C112 | Set block | | 2 |
| 113 | MBS-2128DAS-C113 | Hex. socket cap screw | M12x70L | 4 |
| 114 | MBS-2128DAS-C114 | Steel hex. cap bolt | M16x45L | 4 |
| 115 | MBS-2128DAS-C115 | Spring washer | M16 | 4 |
| 116 | MBS-2128DAS-C116 | Nut | M6 | 1 |
| 117 | MBS-2128DAS-C117 | Spring washer | M6 | 1 |

MBS-2128DAS Bow Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|------------------|-----------------------|-------------|------------|
| 118 | MBS-2128DAS-C118 | Flat washer | M6 | 1 |
| 119 | MBS-2128DAS-C119 | Brush | | 1 |
| 120 | MBS-2128DAS-C120 | Oilless bush | 1212 | 2 |
| 121 | MBS-2128DAS-C121 | Brush sleeve | | 1 |
| 122 | MBS-2128DAS-C122 | Brush cover | | 1 |
| 123 | MBS-2128DAS-C123 | Brush bracket | | 1 |
| 124 | MBS-2128DAS-C124 | Hex. cap bolt | M8x20L | 2 |
| 125 | MBS-2128DAS-C125 | Spring washer | M8 | 2 |
| 126 | MBS-2128DAS-C126 | Flat washer | M8 | 2 |
| 127 | MBS-2128DAS-C127 | Wing screw | M6x10L | 1 |
| 128 | MBS-2128DAS-C128 | Spring washer | M6 | 1 |
| 129 | MBS-2128DAS-C129 | Hex. socket cap screw | M6x20L | 1 |
| 130 | MBS-2128DAS-C130 | Brush shaft | | 1 |
| 131 | MBS-2128DAS-C131 | Nut | M20 | 1 |
| 132 | MBS-2128DAS-C132 | Brush long shaft | | 1 |
| 133 | MBS-2128DAS-C133 | Key | 4x15 | 4 |
| 134 | MBS-2128DAS-C134 | Universal joint | KT-12 | 2 |
| 135 | MBS-2128DAS-C135 | Set screw | M5x6L | 8 |
| 136 | MBS-2128DAS-C136 | Universal joint cover | | 2 |
| 137 | MBS-2128DAS-C137 | Round head screw | M5x8L | 2 |
| 138 | MBS-2128DAS-C138 | Universal joint plate | | 1 |
| 139 | MBS-2128DAS-C139 | Chip motor bracket | | 1 |
| 140 | MBS-2128DAS-C140 | Spring washer | M8 | 2 |
| 141 | MBS-2128DAS-C141 | Hex. socket cap screw | M8x20L | 2 |
| 142 | MBS-2128DAS-C142 | Nut | M6 | 8 |
| 143 | MBS-2128DAS-C143 | Brush motor | | 1 |
| 144 | MBS-2128DAS-C144 | Hex. socket cap screw | M6x90 | 4 |
| 145 | MBS-2128DAS-C145 | Nut | "1/2"" | 4 |
| 146 | MBS-2128DAS-C146 | Spring washer | "1/2"" | 4 |
| 147 | MBS-2128DAS-C147 | Upper bracket | | 1 |
| 148 | MBS-2128DAS-C148 | Spring washer | M10 | 3 |
| 149 | MBS-2128DAS-C149 | Hex. socket cap screw | M10x25L | 3 |
| 150 | MBS-2128DAS-C150 | Spring | 9.0x56x54N | 2 |
| 151 | MBS-2128DAS-C151 | Steel hex. cap bolt | M16x35L | 1 |
| 152 | MBS-2128DAS-C152 | Spring washer | M16 | 1 |
| 153 | MBS-2128DAS-C153 | Driver wheel washer | | 1 |
| 154 | MBS-2128DAS-C154 | Driver wheel | | 1 |
| 155 | MBS-2128DAS-C155 | Guide scale | | 1 |
| 156 | MBS-2128DAS-C156 | Set screw | M10x16L | 4 |
| 157 | MBS-2128DAS-C157 | Hex. socket cap screw | M10x20L | 4 |
| 158 | MBS-2128DAS-C158 | Guide plate | | 1 |
| 159 | MBS-2128DAS-C159 | Locking block | | 2 |
| 160 | MBS-2128DAS-C160 | Guide post (R) | | 1 |
| 161 | MBS-2128DAS-C161 | Set screw | M8x16L | 6 |
| 162 | MBS-2128DAS-C162 | Round head screw | M5x8L | 5 |
| 163 | MBS-2128DAS-C163 | Blade guard | | 1 |
| 164 | MBS-2128DAS-C164 | Thumb screw | M5x6L | 2 |
| 165 | MBS-2128DAS-C165 | Spring pin | 4x12L | 2 |
| 166 | MBS-2128DAS-C166 | Hex. socket cap screw | M10x35L | 4 |
| 167 | MBS-2128DAS-C167 | Spring washer | M10 | 4 |
| 168 | MBS-2128DAS-C168 | Flat washer | M10 | 4 |
| 169 | MBS-2128DAS-C169 | Guide post | | 1 |
| 170 | MBS-2128DAS-C170 | Locking handle | M12x45L | 2 |
| 171 | MBS-2128DAS-C171 | Latch block | | 2 |
| 172 | MBS-2128DAS-C172 | Round head screw | M8x30L | 4 |
| 173 | MBS-2128DAS-C173 | Pin | ψ8x70L | 2 |
| 174 | MBS-2128DAS-C174 | Cover latch | | 2 |
| 175 | MBS-2128DAS-C175 | Round head screw | M6x16L | 4 |
| 176 | MBS-2128DAS-C176 | Blade guard | | 1 |
| 177 | MBS-2128DAS-C177 | Wheel cover | | 1 |


MBS-2128DAS Bow Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|------------------|------------------------------------|----------------|------------|
| 178 | MBS-2128DAS-C178 | . Round head screw | M8x10L..... | 2 |
| 179 | MBS-2128DAS-C179 | . Shaft cover | | 1 |
| 180 | MBS-2128DAS-C180 | . Round head screw | M8x10L..... | 2 |
| 102 | MBS1824DAS-C102 | ... Idle Wheel | | 1 |
| 103 | MBS1824DAS-C103 | ... Hex. Socket Cap Screw | M4x35L..... | 2 |
| 104 | MBS1824DAS-C104 | ... Limit Switch | AZD-S11..... | 1 |
| 105 | MBS1824DAS-C105 | ... Nut | M8..... | 2 |
| 106 | MBS1824DAS-C106 | ... Short Bracket..... | | 1 |
| 107 | MBS1824DAS-C107 | ... Spacer | | 1 |
| 108 | MBS1824DAS-C108 | ... Button Head Socket Screw | M8x25L..... | 4 |
| 109 | MBS1824DAS-C109 | ... Hex. Cap Bolt | M8x20L..... | 1 |
| 110 | MBS1824DAS-C110 | ... Hex. Cap Bolt | M8x20L..... | 1 |
| 111 | MBS1824DAS-C111 | ... Spring Washer..... | M8..... | 1 |
| 112 | MBS1824DAS-C112 | ... Set Screw | M4x12L..... | 2 |
| 113 | MBS1824DAS-C113 | ... Safe Locker | | 1 |
| 114 | MBS1824DAS-C114 | ... Spring | | 1 |
| 115 | MBS1824DAS-C115 | ... Spacer | | 1 |
| 116 | MBS1824DAS-C116 | ... Holding Bracket | | 1 |
| 117 | MBS1824DAS-C117 | ... Bracket Bush | | 1 |
| 118 | MBS1824DAS-C118 | ... Long Bracket | | 1 |
| 119 | MBS1824DAS-C119 | ... Handle | | 2 |
| 120 | MBS1824DAS-C120 | ... Handwheel | | 1 |
| 121 | MBS1824DAS-C121 | ... Set Screw | M8x10L..... | 1 |
| 122 | MBS1824DAS-C122 | ... Key | 5x5x30L..... | 1 |
| 123 | MBS1824DAS-C123 | ... Lead Screw Bushing | | 1 |
| 124 | MBS1824DAS-C124 | ... Bearing | 51203 | 1 |
| 125 | MBS1824DAS-C125 | ... Blade Tension Gauge..... | | 1 |
| 126 | MBS1824DAS-C126 | ... Screw Bushing | | 1 |
| 127 | MBS1824DAS-C127 | ... Plate | | 1 |
| 128 | MBS1824DAS-C128 | ... Nut | M8..... | 1 |
| 129 | MBS1824DAS-C129 | ... Hex. Cap Bolt | M8x60L..... | 1 |
| 130 | MBS1824DAS-C130 | ... Lead Screw | | 1 |
| 131 | MBS1824DAS-C131 | ... Disc Spring | 502225 | 8 |
| 132 | MBS1824DAS-C132 | ... Spring Pin | 5x12L..... | 2 |
| 133 | MBS1824DAS-C133 | ... Spring Bush | | 1 |
| 134 | MBS1824DAS-C134 | ... Hex. Socket Cap Screw | M4x35L..... | 2 |
| 135 | MBS1824DAS-C135 | ... Limit Switch | AZD-1001T..... | 1 |
| 136 | MBS1824DAS-C136 | ... Idle Wheel Washer | | 1 |
| 137 | MBS1824DAS-C137 | ... Ring | S45 | 2 |
| 138 | MBS1824DAS-C138 | ... Idle Wheel Shaft Set..... | | 1 |
| 139 | MBS1824DAS-C139 | ... Slide | | 1 |
| 140 | MBS1824DAS-C140 | ... Pin | 16x90L..... | 1 |
| 141 | MBS1824DAS-C141 | ... Set Screw | M12x25L..... | 1 |
| 142 | MBS1824DAS-C142 | ... Slide Guide | | 2 |
| 143 | MBS1824DAS-C143 | ... Slide Plate | | 2 |
| 144 | MBS1824DAS-C144 | ... Spring Washer..... | M10..... | 6 |
| 145 | MBS1824DAS-C145 | ... Hex. Socket Cap Screw | M10x60L..... | 6 |
| 146 | MBS1824DAS-C146 | ... Idle Wheel Cover | | 1 |
| 147 | MBS1824DAS-C147 | ... Button Head Socket Screw | M6x8L..... | 4 |
| 148 | MBS1824DAS-C148 | ... Limit Switch | AZD-1001T..... | 1 |
| 149 | MBS1824DAS-C149 | ... Hex. Socket Cap Screw | M4x35L..... | 2 |
| 150 | MBS1824DAS-C150 | ... Limit Switch | ED-1-3-32..... | 1 |
| 151 | MBS1824DAS-C151 | ... Hex. Socket Cap Screw | M4x35L..... | 2 |
| 152 | MBS1824DAS-C152 | ... Oilless Bearing | 4040..... | 2 |
| 153 | MBS1824DAS-C153 | ... Spacer | | 2 |
| 154 | MBS1824DAS-C154 | ... Key | 14x9x50..... | 1 |
| 155 | MBS1824DAS-C155 | ... Gear Reducer | 120#1/40 | 1 |
| 156 | MBS1824DAS-C156 | ... Motor | 5HP..... | 1 |
| 157 | MBS1824DAS-C157 | ... Hex. Cap Bolt | M10x35L..... | 4 |

MBS-2128DAS Bow Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|--------------------|--|----------------|------------|
| 158 | MBS1824DAS-C158... | Spring Washer..... | M10..... | 4 |
| 159 | MBS1824DAS-C159... | Washer | M10..... | 4 |
| 160 | MBS1824DAS-C160... | Key | 10x8x40 | 1 |
| 161 | MBS1824DAS-C161... | Wheel Box | | 1 |
| 162 | MBS1824DAS-C162... | Belt | 1922V504 | 1 |
| 163 | MBS1824DAS-C163... | Speed Controlled Wheel (Variable)..... | | 1 |
| 164 | MBS1824DAS-C164... | Speed Controlled Wheel (Fixing) | | 1 |
| 165 | MBS1824DAS-C165... | Hex. Socket Cap Screw | M8x65L..... | 1 |
| 166 | MBS1824DAS-C166... | Wheel Box Cover | | 1 |
| 167 | MBS1824DAS-C167... | Button Head Socket Screw | M5x8L..... | 8 |
| 168 | MBS1824DAS-C168... | Button Head Socket Screw | M5x8L..... | 4 |
| 169 | MBS1824DAS-C169... | Cover Plate..... | | 1 |


MBS-2128DAS Bearing Guide Assembly



MBS-2128DAS Bearing Guide Assembly

| Index No. | Part No. | Description | Size | Qty |
|------------------|-----------------------|-----------------------------------|--------------|------------|
| 1 | MBS-2128DAS-D1 | Bearing long shaft..... | | 2 |
| 2 | MBS-2128DAS-D2 | Bearing..... | 6201..... | 4 |
| 3 | MBS-2128DAS-D3 | Bearing sleeve (long) | | 1 |
| 4 | MBS-2128DAS-D4 | Bearing sleeve (short)..... | | 1 |
| 5 | MBS-2128DAS-D5 | Spring washer | M10..... | 2 |
| 6 | MBS-2128DAS-D6 | Nut..... | M10..... | 2 |
| 7 | MBS-2128DAS-D7 | Hex. socket cap screw | M6x20L..... | 2 |
| 8 | MBS-2128DAS-D8 | Adjusting screw | | 1 |
| 9 | MBS-2128DAS-D9 | Adjusting spring | | 1 |
| 10 | MBS-2128DAS-D10 | Shaft | | 1 |
| 11 | MBS-2128DAS-D11 ... | Hex. socket cap screw | M8x40L..... | 1 |
| 12 | MBS-2128DAS-D12 ... | Front bearing seat | | 1 |
| 13 | MBS-2128DAS-D13 ... | Bearing | 6200..... | 2 |
| 14 | MBS-2128DAS-D14 ... | Bearing bracket | | 1 |
| 15 | MBS-2128DAS-D15 ... | Shaft sleeve..... | | 1 |
| 16 | MBS-2128DAS-D16 ... | Bearing shaft | | 2 |
| 17 | MBS-2128DAS-D17 ... | Carbide guide (Left front) | | 1 |
| 18 | MBS-2128DAS-D18 ... | Carbide guide (Left back) | | 1 |
| 19 | MBS-2128DAS-D19 ... | Spring pin | D5x12L | 2 |
| 20 | MBS-2128DAS-D20 ... | Spring pin | D5x12L | 2 |
| 21 | MBS-2128DAS-D21 ... | Carbide guide (Right back) | | 1 |
| 22 | MBS-2128DAS-D22 ... | Carbide guide (Right front) | | 1 |
| 23 | MBS-2128DAS-D23 ... | Bearing shaft | | 2 |
| 24 | MBS-2128DAS-D24 ... | Bearing bracket | | 1 |
| 25 | MBS-2128DAS-D25 ... | Bearing | 6200..... | 2 |
| 26 | MBS-2128DAS-D26 ... | Shaft sleeve..... | | 1 |
| 27 | MBS-2128DAS-D27 ... | Hex. socket cap screw | M6x20L..... | 2 |
| 28 | MBS-2128DAS-D28 ... | Rear bearing seat..... | | 1 |
| 29 | MBS-2128DAS-D29 ... | Nut | M10..... | 2 |
| 30 | MBS-2128DAS-D30 ... | Spring washer | M10..... | 2 |
| 31 | MBS-2128DAS-D31 ... | Bearing sleeve (long) | | 1 |
| 32 | MBS-2128DAS-D32 ... | Hex. socket cap screw | M8x40L..... | 1 |
| 33 | MBS-2128DAS-D33 ... | Shaft | | 1 |
| 34 | MBS-2128DAS-D34 ... | Adjusting spring | | 1 |
| 35 | MBS-2128DAS-D35 ... | Adjusting screw | | 1 |
| 36 | MBS-2128DAS-D36 ... | Bearing | 6201..... | 4 |
| 37 | MBS-2128DAS-D37 ... | Bearing long shaft | | 2 |
| 38 | MBS-2128DAS-D38 ... | Bearing sleeve (short) | | 1 |

MBS-2128DAS Coolant System




MBS-2128DAS Coolant System


| Index No. | Part No. | Description | Size | Qty |
|------------------|---------------------|----------------------------|-------------------|------------|
| 1 | MBS-2128DAS-E1..... | Cock | 1/4x1/4..... | 1 |
| 2 | MBS-2128DAS-E2..... | Spring washer | M12..... | 1 |
| 3 | MBS-2128DAS-E3..... | Fixing bracket..... | | 1 |
| 4 | MBS-2128DAS-E4..... | Fitting | 1/4x1/4..... | 1 |
| 5 | MBS-2128DAS-E5..... | Big round head screw | M6x8L..... | 2 |
| 6 | MBS-2128DAS-E6..... | Fitting | 1/4x1/4..... | 1 |
| 7 | MBS-2128DAS-E7..... | Hose | 1/4"x220mm | 1 |
| 8 | MBS-2128DAS-E8..... | Hose | 1/4"x2400mm | 1 |
| 9 | MBS-2128DAS-E9..... | Cock | 1/4x1/4..... | 1 |
| 10 | MBS-2128DAS-E10.... | Nozzle set..... | | 1 |
| 11 | MBS-2128DAS-E11.... | Nozzle | | 1 |
| 12 | MBS-2128DAS-E12.... | Y Fit | | 1 |
| 13 | MBS-2128DAS-E13.... | Hose | 1/4"x3100mm | 1 |
| 14 | MBS-2128DAS-E14.... | Hose | 1/4"x1700mm | 1 |
| 15 | MBS-2128DAS-E15.... | Cock | 1/4x1/4..... | 1 |
| 16 | MBS-2128DAS-E16.... | 90° Fitting | 1/4x1/8..... | 1 |
| 17 | MBS-2128DAS-E17.... | Fitting..... | 3/8x1/4..... | 1 |
| 18 | MBS-2128DAS-E18.... | 90° Fitting | 3/8x1/4..... | 1 |
| 19 | MBS-2128DAS-E19.... | Fitting Set | 3/8..... | 1 |
| 20 | MBS-2128DAS-E20.... | 90? Fitting..... | 1/2x3/8..... | 1 |
| 21 | MBS-2128DAS-E21.... | Coolant pump | 1/6"x150L | 1 |
| 22 | MBS-2128DAS-E22.... | Hose | 1/4"x2400mm | 1 |

MBS-2128DAS...50000343T 3~400V, 50Hz

Control Circuit Diagram



Panel Board Wiring Diagram



Saw Bow Stroke Wiring Diagram

