



JSG-48EVS

Disc & Belt Sander

JR124 1 ~230V 50Hz


PARTS LIST



Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17
www.jettools.ru
Made in PRC / Сделано в КНР

P-JR124 2026-09

Parts Breakdown for JSG-48EVS Disc & Belt Sander



Parts List for JSG-48EVS Disc & Belt Sander

Index No.	Part No.	Description	Size	Qty
1	JSG48EVS-001	Pan Head Screw	M5×205	4
2	GB276	Ball Bearing	6004-2RS	1
3	JSG48EVS-003	Wave Retaining Ring	40mm	1
4	GB276	Ball Bearing	6004-2RS	1
5	JSG48EVS-005	Rotor		1
6	JSG48EVS-006	Stator		1
7	JSG48EVS-007	External Tooth Lock Washer	4mm	1
8	JSG48EVS-008	Pan Head Screw	M4×7	1
9	JSG48EVS-009	Flange Nut	M5	4
10	JSG48EVS-010	Housing		1
11	GB818	Pan Head Cap Screw	M5×8	10
12	JSG48EVS-012	Self-Tapping Screw	ST2.9×6.5	6
13	JSG48EVS-013	Inverter Circuit Board with Display Panel		1
14	JSG48EVS-014	Switch Panel		1
15	GB70.1	Socket Head Cap Screw	M6×10	1
16	JSG48EVS-016	Socket Head Cap Screw	M6×15	6
17	GB6170	Hex Nut	M6	1
18	JSG48EVS-018	Dust Suction Nozzle Connector		1
19	JSG48EVS-019	Sanding Disc Guard		1
20	GB818	Pan Head Screw and Plain Washer	M4×8	2
21	JSG48EVS-021	Workbench Bracket		1
22	JSG48EVS-022	Abrasive Belt Workbench		1
23	JSG48EVS-023	Locking Handle		2
24	GB819.1	Flat Head Screw	M5×10	2
25	GB818	Pan Head Screw and Plain Washer	M5×12	4
26	JSG48EVS-026	Foot		4
27	JSG48EVS-027	Locking Handle Assembly	M8×25	1
28	GB818	Pan Head Screw and Plain Washer	M5×25	1
29	JSG48EVS-029	Abrasive Belt Bracket Support Assembly		1
30	JSG48EVS-030	Drive Roller		1
31	GB80	Socket Set Screw	M8×12	2
32	JSG48EVS-032	Handle		1
33	GB6170	Hex Nut	M10	1
34	JSG48EVS-034	Baffle		1
35	JSG48EVS-035	Bracket Fixing Plate		1
36	JSG48EVS-036	Positioning Shaft	M6×12	1
37	GB70.1	Socket Head Cap Screw	M6×25	1
38	JSG48EVS-038	Base Plate		1
39	GB9074.13	Socket Head Cap Screw, Spring Washer	M6×12	4
40	JSG48EVS-040	Bracket Assembly		1
41	JSG48EVS-041	Compression Spring		1
42	JSG48EVS-042	Protective Sleeve		2
43	JSG48EVS-043	Guide Frame		1
44	GB894	Shaft Circlip	12mm	2
45	GB276	Ball Bearing	6001-2RS	2
46	JSG48EVS-046	Driven Roller		1
47	JSG48EVS-047	Driven Shaft		1
48	GB95	Flat Washer	8mm	3
49	JSG48EVS-049	Sharpening Plate		1
50	JSG48EVS-050	Abrasive Belt Adjusting Handle		1
51	JSG48EVS-051	Adjusting Spring		1
52	JSG48EVS-052	Rubber Washer		1
53	GB96.1	Large Washer	6mm	2
54	JSG48EVS-054	Upper Abrasive Belt Dust Suction Port		1

Parts List for JSG-48EVS Disc & Belt Sander

Index No.	Part No.	Description	Size	Q'ty
55	JSG48EVS-055	Lower Abrasive Belt Dust Suction Port		1
56	JSG48EVS-056	Abrasive Belt Dust Suction Port Cover		1
57	JSG48EVS-057	Tension Pull Plate		1
58	JSG48EVS-058	Right Support for Sanding Disc Table		1
59	JSG48EVS-059	Left Support for Sanding Disc Table		1
60	JSG48EVS-060	Bushing		1
61	GB818	Pan Head Screw, Washer	M5×16	1
62	JSG48EVS-062	Tension Spring		1
63	JSG48EVS-063	Screw Cover		2
64	JSG48EVS-064	Panel Label		1
65	JR148 (JSG48EVS-065)	Velcro base disc 203mm		1
66	GB9074.4	Pan Head Screw + Spring Washer	M5×8	2
67	JSG48EVS-067	Pointer		2
68	JR149 (JSG48EVS-068)	Sanding belt 100x915mm 80G	80G	1
69	JSG48EVS-069	Hex Key Wrench	S=5	1
70	JSG48EVS-070	Sanding Disc Guard End Cover		1
71	JSG48EVS-071	Right End Cover		1
72	JSG48EVS-072	Power Lead		1
73	JSG48EVS-073	Speed Adjustment Knob		1
74	JSG48EVS-074	Sanding Disc Pad		1
75	JR145 (JSG48EVS-075)	Sanding disc 203mm 80 gr for JSG-48EVS	80G	1
76	GB9074.1	Pan Head Screw + Washer	M4×12	5
77	JSG48EVS-077	Sanding Disc Workbench		1
78	JSG48EVS-078	Workbench Pointer		1
79	JSG48EVS-079	Locking Handle Assembly	M8×20	2
80	GB9074.4	Pan Head Screw +Washer	M5×12	1
81	JSG48EVS-081	Index Plate Handle		1
82	JSG48EVS-082	Sanding Disc Dust Suction Port		1
83	JSG48EVS-083	Index Plate		1
84	JSG48EVS-084	Miter Bar		1
85	JSG48EVS-085	Cylindrical Pin		1
86	GB818	Pan Head Screw	M3×10	2
87	JSG48EVS-087	Three-Pin Socket		1
88	JSG48EVS-088	Sanding Disc Plate		1
89	JSG48EVS-089	Parallel Key	C 4.8×4.8×15	1
90	GB819.2	Flat Head Cap Screw	M6×16-LH	1
91	JSG48EVS-091	Guide Rod		1
92	GB889.1	Lock Nut	M12	1
93	GB6170	Hex Nut	M12	1
94	GB9074.1	Pan Head Screw + Washer	M5×10	1
95	GB818	Pan Head Cap Screw	M5×8	2
96	GB845	Pan Head Self-Tapping Screw	ST2.9×5	4
	JSG48EVS-WL	JET Warning Label (Not shown)		1
	JSG48EVS-ID	JET ID Label (Not shown)		1
	JSG48EVS-ML	JET Motor Label (Not shown)		1
	JET-LOGO	JET Logo with Adhesive (Not shown)		1
	JET Model Logo	JET Model Logo with Adhesive		1

Wiring Diagram for JSG-48EVS Disc & Belt Sander

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschuttschalter	déclencheur surcharge
L	machine lamp	Maschinenleuchte	lampe
LS	limit switch	Positionsendschalter	micro

JR124..... ~ 230V, 50Hz

