



JWP-13

THICKNESSER PLANER

JWP-13.....JR122.....~230V/50Hz/1Ph

PARTS LIST




**Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д.17
www.jettools.ru**


Made in PRC / Сделано в КНР

P- JR122 2026-09

Parts Breakdown for JWP-13 Thickness Planer



Parts Breakdown for JWP-13 Thickness Planer



Parts List for JWP-13 Thickness Planer

Index No.	Part No.	Description	Size	Qty
1	GB/T 5281	Hex Socket Shoulder Screw	M 8×16	1
2	JWP13-002	Lifting Handle		1
3	GB70.2	Socket Button Head Cap Screw	M5x12	42
4	JWP13-004	Lifting Crank Handle		1
5	JWP13-005	Wave Spring Washer	26mm	1
6	JWP13-006	Dial Scale		1
7	JWP13-007	Wire Circlip For Shaft	18mm	1
8	JWP13-008	Upper Right Cover		1
9	GB93	Spring Washer	5mm	47
10	JWP13-010	Needle Roller Bearing F-1212	F-1212	2
11	JWP13-011	Limit Sleeve		1
12	JWP13-012	Eccentric Tension Spring		4
13	GB/T 9074.1	Socket Cap Screw & Spring Washer	M5×30	6
14	GB96.1	Large Flat Washer	5mm	4
15	JWP13-015	Right Tension Bracket		1
16	JWP13-016	Light Duty Straight Slotted Spring Pin	4×16	4
17	JWP13-017	Locking Block		4
18	JWP13-018	Sliding Block		2
19	JWP13-019	L-Type Magnetic Hex Wrench		1
20	JWP13-020	Hex Wrench - 3	3	1
21	GB/T 9074.1	Socket Cap Screw & Spring Washer	M5×30	2
22	JWP13-022	Chip Discharge Port		1
23	GB6170	Socket Cap Screw + Washer	M5×25	2
24	JWP13-024	Pan Head Self-Tapping Screw	ST4.2×10	9
25	JWP13-025	Chip Guide Plate		1
26	JWP13-026	Rubber O-Ring - $\Phi 6 \times \Phi 1.5$	$\Phi 6 \times \Phi 1.5$	4
27	JWP13-027	Chip Guide Groove		1
28	JWP13-028	Scraper Plate		1
29	JWP13-029	Sponge Strip		1
30	JWP13-030	Series Wound Motor		1
30A	JWP13-30A	Brush Assembly		1
30.1	JWP13-30.1	Brush Holder		1
30.2	JWP13-30.2	Carbon Brush		1
30.3	JWP13-30.3	Brush Cap		1
31	JWP13-031	Motor Poly V-Belt Pulley		1
32	JWP13-032	Copper-Based Powder Bearing 1		2
33	JWP13-033	1st Stage Shaft Spur Gear		1
34	JWP13-034	1st Stage Gear Shaft		1
35	JWP13-035	2nd Stage Shaft Gear		1
36	JWP13-036	2nd Stage Gear Shaft		1
37	JWP13-037	Output Shaft Gear		1
38	JWP13-038	Powder Bearing 1		1
39	JWP13-039	General Flat Key, Type C - C4×4×10		2
40	GB/T 9074.1	Socket Cap Screw & Spring Washer	M5×8	4
41	JWP13-041	Lead Screw Nut		2
42	JWP13-042	Hex Thin Nut - M16×1.5-L	M16x1.5-L	1
43	JWP13-043	Poly V-Belt		1
44	JWP13-044	Driven Poly V-Belt Pulley		1
45	JWP13-045	Internal Circlip - 47	47mm	1
46	JWP13-046	Deep Groove Ball Bearing	6303ZZCM-NSK	1
47	JWP13-047	2-Flute 3-Hole Cutter Shaft		1
48	JR162	Cutting Knife (Blades) HSS for JWP-13 1 set by 2pcs		2
49	JWP13-049	Compression Spring For Cutter Shaft		4
50	GB70.2	Socket Button Head Screw	M6×16	20

Parts List for JWP-13 Thickness Planer

Index No.	Part No.	Description	Size	Qty
51	JWP13-051	Cutter Retaining Strip		2
52	JWP13-052	Right Side Plate		1
53	JWP13-053	Bevel Gear		4
54	JWP13-054	Compression Spring For Gear Shaft		1
55	GB96.1	Large Washer	6 mm	2
56	GB889.1	Hex Lock Nut	M6	2
57	GB77	Socket Flat Point Set Screw	M6×25	2
58	GB70.2	Socket Button Head Screw	M5x8	4
59	GB93	Spring Washer	6mm	4
60	GB95	Flat Washer	6mm	4
61	GB6170	Hex Nut	M6	10
62	GB95	Flat Washer	10mm	1
63	JWP13-063	Bevel Gear Connecting Shaft		1
64	JWP13-064	Bevel Gear Housing		2
65	GB889.1	Hex Lock Nut	M5	3
66	JWP13-066	Base		1
67	GB894	Shaft Circlip	10mm	1
68	GB95	Flat Washer	5mm	22
69	JWP13-069	Extension Bracket		4
70	JWP13-070	Saddle Spring Washer -	8mm	4
71	JWP13-071	Hexagon Socket Shoulder Eccentric Screw		4
72	JWP13-072	Auxiliary Worktable		2
73	JWP13-073	Lifting Screw Rod		1
74	GB276	Deep Groove Ball Bearing - 61900-2rz	61900-2RZ	2
75	JWP13-075	Bearing Press Plate		2
76	JWP13-076	Gear Cover		2
77	GB70.2	Socket Button Head Screw	M4x10	6
78	GB93	Spring Washer	4	4
79	JWP13-079	Spring Steel Sheet		2
80	GB/T 5783	Hex Cap Screw	M6×20	4
81	JWP13-081	Guide Pin		4
82	JWP13-082	Left Lifting Screw Rod		1
83	JWP13-083	Worktable Base Plate		1
84	JWP13-084	Base Plate Retaining Strip		2
85	GB/T9074.4	Pan Head Screw,+Washer	M5×10	8
86	JWP13-086	Roller Press Plate		4
87	JWP13-087	Roller Bearing		4
88	JWP13-088	Infeed Roller (Black Rubber)		1
88.1	JWP13-0881	Outfeed Roller (PU) (Light-colored)		1
89	JWP13-089	Left Side Plate		1
90	JWP13-090	Compression Spring For Rubber Roller		4
91	JWP13-091	Reduction Sprocket		3
92	JWP13-092	Shaft Circlip	15mm	3
93	JWP13-093	Reduction Chain		1
94	JWP13-094	Socket Cap Screw + Flat Washer	M6×15	2
95	JWP13-095	Lifting Base		1
96	GB/T 28698	Deep Groove Ball Bearing	6002-2RZ	1
97	JWP13-097	Sprocket Torsion Spring		1
98	JWP13-098	Internal Circlip	32 mm	2
99	JWP13-095	Sprocket Tension Plate		1
100	GB/T5281	Socket Shoulder Screw	6.5×16	1
101	JWP13-101	Compression Spring For Cutter Shaft		1
102	JWP13-102	Press Plate For Cutter Shaft Positioning Plate		1
103	JWP13-103	Electromagnetic Switch	KJD20-2	1
104	GB845	Pan Head Self-Tapping Screw	ST3.5×9.5	2

Parts List for JWP-13 Thickness Planer

Index No.	Part No.	Description	Size	Qty
105	JWP13-105	Electrical Box Panel		1
106	JWP13-106	Overcurrent Protector		1
107	GB845	Pan Head Self-tapping Screw	ST3.5×16	1
108	JWP13-108	Micro Switch - HY50		1
109	JWP13-109	Electrical Box		1
110	JWP13-110	Cutter Shaft Positioning Plate		1
111	JWP13-111	Wire Fixing Plate		1
112	JWP13-112	Wire Fastener - UL-1/4		1
113	GB845	Pan Head Self-tapping Screw	ST4.2×12.7	2
114	JWP13-114	Limit Switch Base		1
115	GB9074.4	Pan Head Screw+ Spring Washer	M4×12	1
116	GB70.1	Socket Head Cap Screw	M4x10	1
117	JWP13-117	Cable Grommet		1
118	JWP13-118	Cylindrical Pin	φ4×12	2
119	GB9074.4	Pan Head Screw+ Spring Washer	M5×18	3
120	JWP13-120	Power Cord		1
121	JWP13-121	Gear Box Housing		1
122	JWP13-122	Copper-Based Powder Bearing 2		2
123	JWP13-123	Powder Bearing 2		1
124	JWP13-124	Gear Box Output Shaft		1
125	JWP13-125	Tension Bracket		1
126	JWP13-126	Left Tension Bracket		1
127	JWP13-127	Belt Cover Plate		1
128	JWP13-128	Eccentric Shaft		1
129	JWP13-129	Locking Handle		1
130	JWP13-130	Eccentric Wheel		1
131	JWP13-131	Eccentric Compression Spring		1
132	JWP13-132	Slotted Hex Dipped Plastic Bolt M8×12		2
133	JWP13-133	Short Tension Rod		1
134	JWP13-134	Eccentric Wheel Bracket		1
135	JWP13-135	Steel Ball - D6		1
136	JWP13-136	Compression Spring for Tension Handle		1
137	GB77	Socket Flat Point Set Screw	M8×8	1
138	JWP13-138	Eccentric Wheel Torsion Spring		1
139	GB/T845	Pan Head Self-tapping Screw	ST4.8×16-F	6
140	GB97.1	Flat Washer	6mm	4
141	GB93	Spring Washer	6mm	4
142	JWP13-142	Upper Left Cover		1
143	JWP13-143	Upper Cover		1
144	GB889.1	Hex Lock Nut	M8	1
145	GB95	Flat Washer	8mm	1
146	GB70.1	Socket Head Cap Screw	M5×8	1
147	GB70.1	Socket Head Cap Screw	M6×40	1
148	JWP13-148	Long Tension Rod		1
149	JWP13-149	Lampshade		1
150	JWP13-150	Switch Panel		1
151	JWP13-151	Pointer		1
152	JWP13-152	Depth Probe Bracket		1
153	JWP13-153	Cutting Depth Pointer A		1
154	JWP13-154	Depth Probe A		1
155	JWP13-155	Probe Compression Spring		1

Parts List for JWP-13 Thickness Planer

Index No.	Part No.	Description	Size	Qty
156	JWP13-156	Probe Pointer Rotating Screw		1
157	JWP13-157	External Indication		1
158	GB818	Pan Head Cap Screw	M4×10	3
159	JWP13-159	Led switch	HY17-2P	3
160	JWP13-160	Transformer	3V	3
161	JWP13-161	Light strip		3
162	JWP13 -162	Cutting Depth Indication		1
163	JWP13 -163	Cutting Indicator Locating Sleeve		1
164	JWP13 -164	Bevel Gear Pointer		1
165	JWP13 -165	Depth Probe		1
166	JWP13 -166	Compression Spring		1
167	GB6170	Hex Nut	M4	1
	JWP13-WL	JET Warning Label (Not shown)		1
	JWP13-ID	JET ID Label (Not shown)		1
	JWP13ML	JET Motor Label (Not shown)		1
	JWP13JET LOGO	JET- Logo		1

Wiring Diagram for JWP-13 Thickness Planer

JR122..... ~ 230V, 50Hz

