



JWP-209HH THICKNESSER


**1791316T
400/50/3**

PARTS LIST

Walter Meier (TOOL) AG
Täumperlistr. 5
CH-8117 Fällanden
Switzerland
Phone +41 44 806 47 48
Fax +41 44 806 47 58
jetinfo.eu@waltermeier.com
www.jettools.com



JWP-209HH Cutterhead Assembly



JWP-209HH Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6012204	Nut	5/16-18NC	2
3.....	209HH-1003.....	Belt	3
4.....	6292696	Bolt	2
5.....	6292639	Hex Head Bolt	M8 x 1.25P x 20L	2
6.....	6292631	Washer	8 x 30 x 3	1
7.....	6292660	Hex Head Bolt With Washer	M6 x 1.25P x 20L	16
9.....	6292698	Hex Nut.....	5/16"-18NC	2
10.....	6292630	Machined Pulley	1
11.....	6292633	Motor Pulley	1
12.....	6292672	Collector Tube	1
13.....	6292654	Hex Head Bolt	M6 x 1.0P x 12L	10
14.....	6292653	Washer	1/4	12
15.....	TS-1482011.....	Hex Cap Screw	M6 x 1.0P x 10L	6
16.....	6292670	Upper Cover	1
17.....	6292814	Flat Washer	8.5 x 23 x2T	4
18.....	7292675	Hex Cap Screw	M6 x 1.0P x 16L	9
19.....	6292682	Handwheel	1
20.....	6292684	Handle	1
22.....	6292663	Chip Deflector.....	1
23.....	6292652	Plate Spring.....	3
24.....	6292640	Set Screw	M6 x 1.0P x 16	9
25.....	6292662	Plate Spring.....	0.6	1
26.....	6292637	Screw.....	M22 x 1.5P x 20	4
27.....	6292720	Collar	1
28.....	6292716	Bracket	1
29.....	6292717	Shaft	1
30A	209HH-IPA	Idle Pulley Assembly (index no. 14,30,31,91,112).....	1
30.....	6292715	Idle Pulley	2
31.....	6292714	Shaft	2
32.....	6292693	Safety Hatch.....	1
33.....	6292690	Spring Pin	6 Dia x20	2
34.....	6292689	Cover	1
35.....	6292694	Socket Head Cap Screw	M8 x 1.25P x 40L	1
36.....	6292719	Spring	1
37.....	6292718	Hanger.....	1
38.....	6292817	Round Head Screw	M6 x 1.0P x 12L	1
39.....	6292818	Hex Head Bolt	M8 x 1.25P x 18L	4
41.....	6296255	Safety Hatch.....	1
43.....	6292618	Set Screw	M10 x 1.5P x 12L	8
44.....	TS-1524031.....	Set Screw	M8 x 1.25P x 12L	5
45.....	6292617	Casting Head.....	1
46.....	6292659	Shaft	2
47.....	6292705	Rivet	4
48.....	6292641	Hex Nut.....	M6 x 1.0P	8
49.....	6292661	Set Screw	M6 x 1.0 x 20L.....	2
50.....	6292669	Flat Head Machine Screw	M6 x 0.8P x 8L	2
51.....	6292668	Cut Limiter Plate	1
52.....	6292687	Cut Limiter Pointer.....	1
53.....	6292685	Scale.....	1
54.....	BB-6206ZZ	Bearing	6206ZZ-2NSE	1
55.....	6292629	Key	8 x 8 x 36	1
58.....	6292636	Spring	4
59.....	6292635	Bushing.....	4


JWP-209HH Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
60.....	6292638	Plate	4
61.....	6292658	Lock Washer	2
62.....	6292657	Pressure Plate.....	1
63.....	6292646	Outfeed Roller	1
64.....	6292642	Key	5 x 5 x 23.....	2
65.....	6292647	Sprocket	1
66.....	6292644	Washer	6.2 x 20 x 3T	2
67.....	6292645	Hex Head Bolt	M6 x 1.0P x 16L	2
68.....	6292656	Bracket	1
69.....	6292655	Shaft	1
70.....	6292650	Chip Breaker	1
71.....	6292643	Sprocket	31T	1
72.....	6292649	Retaining Ring.....	STW-12.....	2
73.....	6292667	Retaining Ring.....	2
74.....	6292665	Collar	56
75.....	6292664	Anti-kickback Finger.....	55
76.....	6292648	Locking Bolt.....	1
77.....	6292666	Shaft	1
78.....	6292651	Nut	M12 x 1.75P	2
79.....	6292634	Infeed Roller	1
80.....	6292706	Chain	06B	1
81.....	6292673	Roller Stand.....	3
82.....	6292674	Roller	2
83.....	6292678	Gear Box Worm.....	1
84.....	6292677	Hex Socket Cap Screw	M6 x 1.0P x 50L	3
85.....	6292676	Worm	1
86.....	6292681	Key	4 x 4 x 10.....	1
87.....	6292679	Bearing	6201Z	1
88.....	6292680	Retaining Ring.....	RTW-32.....	1
89.....	6292713	Collar	1
90.....	6292683	Washer	1/2	1
91.....	6292813	Hex Socket Cap Screw	M6 x 1.0P x 10L	1
92.....	6292821	Hex Socket Cap Screw	M5 x 0.8P x 10L	3
93.....	6292815	Hex Head Bolt	M6 x 1.0P x 16L	5
94.....	209-1094	Sponge	2
95.....	209-1095	Pulley Guard.....	1
96.....	209-1096	Pulley Cover	1
97.....	209-1097	Strain Relief, Momentary Switch Cord	1
98.....	TS-1540031.....	Hex Nut.....	M5 x 0.8P	2
99.....	TS-1550031.....	Flat Washer	5 x 12 x 0.8T	4
100.....	209-1100	Switch Box	1
101.....	209-1101	Switch, Off	1
102.....	209-1102	Switch, On	1
103.....	209-1103	Switch Plate	1
104.....	TS-1481041.....	Hex Cap Screw	M5 x 0.8P x 16L	2
105.....	209-1105AE	Cord	1
106.....	6012192	Warning Label	1
107.....	6292820	Label	1
108.....	6292819	Label, Lubrication	1
109.....	1791275E	Helical Cutterhead	1
110.....	1791212E	Knife Insert (set of 10)	total 138
111.....	15HH-2102E.....	Knife Insert Screw	138
112.....	209HH-1112	Bracket	1

JWP-209HH Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
113.....	TS-2361081.....	Lock Washer	M8	1
114.....	TS-1490051.....	Hex Cap Screw	M8 x 1.25P x 30	1
115.....	209HH-1115.....	Set Screw	M6 x 1.0P x 16	2
.....	JJ6HH-113	Star Point Screwdriver (not shown).....		2


JWP-209HH Base Assembly



JWP-209HH Base Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292649	Ring, Retaining	STW-12	1
2.....	6292742	Gear	24T	1
3.....	6292740	Retaining Ring	RTW-38	1
4.....	6292739	Bushing	1
5.....	6292738	Nut	4
6.....	6292741	Key	4 x 4 x 10	1
7.....	6292737	Lead Screw	1
8.....	6292758	Expansion Bend	8
9.....	209-309	Machined Screw	M5 x 2.12P x 10L	30
10.....	6292756	Pipe Band	16
11.....	6292735	Column	1
12.....	6292755	Retaining Ring, ETW-19	4
13.....	6292754	Crane Post	4
14.....	6285855	Bearing	6202ZZ	4
15.....	6292744	Retaining Ring, RTW-35	4
16.....	6292746	Sprocket	10T	4
17.....	209-317	Flat Washer	10 x 19 x 1.5T	4
18.....	6292627	Hex Nut	M10 x 1.25P	4
19.....	6292747	Flat Washer	8.2 x 22 x 3T	2
20.....	6292748	Hex Head Bolt	M8 x 1.25P x 25L	2
21.....	6292618	Set Screw	M10 x 1.5P x 12	8
22.....	6292753	Chain	40 x 166P	1
23.....	6292749	Bracket	1
24.....	6292750	Shaft	1
25.....	6292751	Sprocket	10T	1
26.....	6292752	Retaining Ring	STW-15	1
27.....	6292736	Lead Screw	1
28.....	6292734	Column	3
29.....	6292733	Base	1
30.....	209-330	Gasket	1
31.....	209-331	Screw	M5 x 0.8P x 18L	2


JWP-209HH Gearbox Assembly



JWP-209HH Gearbox Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292788	Socket Head Cap Screw	M6 x 1.0P x 25L	5
2.....	6292785	Pin	8 x20.....	2
3.....	6292787	Cover	1
4.....	6292765	Bearing	6201	4
5.....	6292768	Key	5 x 5 x12.....	1
6.....	6292767	Shaft	18T	1
7.....	6292766	Gear	47T	1
8.....	6292762	Gear	16T	1
9.....	6292761	Bearing	6204ZZ	2
10.....	TS-1503041.....	Socket Head Cap Screw	M6 x 1.0P x 16L	1
11.....	6292764	Flat Washer	1
12.....	6292790	Hex Socket Cap Screw	M8 x 1.25P x 50L	4
13.....	TS-1482031.....	Hex Head Bolt	M6 x 1.0P x 16L	1
14.....	6292779	Sprocket	12T	1
.....	6292791	Sprocket	18T	1
15.....	6292780	Chain	06B x 50P	1
.....	209HH-415	Chain	06B x 53P	1
.....	6292822	Low Speed Gear Kit (includes #14-6292779 and #15-6292780)
16.....	6292784	Knob	1
17.....	6292654	Hex Head Bolt	M6 x 1.0P x 12L	1
18.....	6292769	Gear	71T	1
19.....	6292770	Key	5 x 5 x 10.....	1
20.....	6292774	Key	6 x 6 x 40.....	1
21.....	6292771	Shaft	18T	1
22.....	6292763	Hex Socket Cap Screw	M6 x 1.0P x 20L	1
23.....	6292778	Oil Seal	SC24 x 47 x 6.....	1
24.....	6292775	Ball	Ø 6.....	1
25.....	6292776	Spring	1
26.....	6292777	Shaft	1
27.....	6292772	Gear Assembly	1
28.....	6292786	Piece Packing	1
29.....	6292789	Oil Plug	PT1/4"-19	2
30.....	6292759	Gear Box	1
31.....	6292760	Oil Seal	1
32.....	6292783	Oil Ring	1
33.....	6292782	Handle	1
34.....	6292781	Clutch	1


JWP-209HH Stand Assembly



JWP-209HH Stand Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292807	Strain Relief.....	1
2.....	6292804	Key	1
3.....	6292802	Hex Nut.....	M8 x 1.25P	4
4.....	TS-1550061.....	Flat Washer	8.5 x 16 x 1.5T	4
5.....	6292651	Hex Nut.....	.M12 x 1.75P	8
6.....	6292683	Washer	1/2	12
7.....	6292799	Adjusting Bolt	2
8.....	6292798	Collar	1
9.....	6292711	Set Screw	M8 x 1.25P x 8L	5
10.....	209HH-5010.....	Motor Mount	1
11.....	TS-1550061.....	Washer	8.5 x 23 x 2T	4
12.....	TS-1490071.....	Hex Head Bolt	M8 x 1.25P x 40L	4
13.....	6292796	Bar	2
14.....	6292794	Cover	1
15.....	6292795	Machine Screw	M6 x 1.0P x 20	4
16.....	209HH-5016AE	Magnetic Switch	5HP 3PH 400V	1
17.....	6296136	Pan Head Machine Screw.....	#10-24NC x 1/2L.....	2
18.....	209-5018	Lock Knob	5/16-18NC x 3/4	2
19.....	209HH-5019	Stand	1
20.....	TS-1490031.....	Hex Cap Screw	M8 x 1.25P x 20	4
21.....	209-5021	Wheel	4
22.....	TS-1541031.....	Nylon Hex Nut	M8	4
.....	209HH-5023AE	Motor	5HP, 3Ph, 400V	1
.....	209HH-5023F	Motor Fan (not shown)	1
.....	209HH-5023FC	Motor Fan Cover (not shown)	1
24.....	209-524	Switch Plate.....	1
25.....	209-1097	Strain Relief, Momentary Switch Cord	1
26.....	209-526AE	Power Cord w/P551 Plug	1
27.....	209-527AE	Cord, Motor to Switch.....	1
28.....	6292805	Hex Head Bolt	M12 x 1.75P x 60L	4
29.....	6292757	Machined Screw.....	M5 x 0.8P x 8L	4
31.....	TS-0810012	Slotted Round Head Machine Screw	#10-24 x 1/4	1
34.....	209-5034	Screw.....	M5 x 0.8P x 6	2
36.....	209-5036	Strain Relief	1
37.....	209-5037	Junction Box	1
38.....	209-5038	Junction Box Cover	1

JWP-209HH Table Assembly



Index No.	Part No.	Description	Size	Qty
1.....	6292724	Eccentric Shaft		4
2.....	6292679	Bearing	6201Z	4
3.....	6292722	Roll		2
4.....	6292728	Knob		2
5.....	6292727	Locksmith		2
6.....	TS-1523041	Set Screw	M6 x 1.0P x 12L	4
7.....	6292724	Eccentric Shaft		4
8.....	6292729	Socket Head Cap Screw	M8 x 1.25P x 16L	8
9.....	6292726	Locking Bolt		2
10.....	6292725	Locking Bar		2
11.....	209-2011	Table		1
12.....	209-2012	Extension		2
13.....	TS-1490041	Hex Cap Screw	M8 x 1.25P x 25L	6
14.....	TS-1504041	Socket Head Set Screw	M8 x 1.25P x 20L	6

JWP-209HH
1791316T
400/50/3

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
LS	limit switch	Positionendschalter	Micro

